




ITT

Goolds Pumps

Installation, Operation, and Maintenance Manual

**Model 3700, API Type OH2 / ISO 13709 1st and 2nd
Editions / API 610 8th, 9th, 10th, and 11th Editions**



Engineered for life

Table of Contents

Introduction and Safety	4
Introduction.....	4
Requesting other information.....	4
Safety.....	4
Safety terminology and symbols.....	5
Environmental safety.....	5
User safety.....	6
Product approval standards.....	7
Safety regulations for Ex-approved products in potentially explosive atmospheres.....	7
Product warranty.....	8
Transportation and Storage	10
Inspect the delivery.....	10
Inspect the package.....	10
Inspect the unit.....	10
Transportation guidelines.....	10
Pump handling.....	10
Lifting methods.....	10
Storage guidelines.....	12
Pump storage requirements.....	12
Frostproofing.....	12
Product Description	13
General description 3700.....	13
Nameplate information.....	14
Installation	18
Preinstallation.....	18
Pump location guidelines.....	18
Foundation requirements.....	19
Baseplate-mounting procedures.....	19
Prepare the baseplate for mounting.....	19
Prepare the foundation for mounting.....	20
Install the baseplate using jackscrews.....	20
Install the pump, driver, and coupling.....	21
Pump-to-driver alignment.....	22
Alignment checks.....	22
Permitted indicator values for alignment checks.....	23
Alignment measurement guidelines.....	23
Attach the dial indicators for alignment.....	23
Pump-to-driver alignment instructions.....	24
Grout the baseplate.....	27
Piping checklists.....	28
General piping checklist.....	28
Suction-piping checklist.....	29
Discharge piping checklist.....	32
Bypass-piping considerations.....	33
Auxiliary-piping checklist.....	33
Final piping checklist.....	33
Commissioning, Startup, Operation, and Shutdown	34
Preparation for startup.....	34

Remove the coupling guard.....	34
Check the rotation.....	35
Couple the pump and driver.....	36
Coupling guard assembly.....	36
Bearing lubrication.....	45
Shaft sealing with a mechanical seal.....	47
Connection of sealing liquid for mechanical seals.....	48
Pump priming.....	48
Prime the pump with the suction supply above the pump.....	48
Prime the pump with the suction supply below the pump.....	49
Other methods of priming the pump.....	50
Start the pump.....	50
Pump operation precautions.....	51
Shut down the pump.....	52
Make the final alignment of the pump and driver.....	52
Dowel the pump casing (optional).....	53
Maintenance.....	54
Maintenance schedule.....	54
Bearing maintenance.....	55
Mechanical-seal maintenance.....	55
Disassembly.....	56
Disassembly precautions.....	56
Tools required.....	56
Drain the pump.....	57
Remove the back pull-out assembly.....	57
Remove the coupling hub.....	58
Remove the impeller.....	58
Remove the seal-chamber cover.....	59
Remove the optional water-jacket cover.....	60
Disassemble the power end.....	61
Preassembly inspections.....	66
Replacement guidelines.....	66
Shaft replacement guidelines.....	68
Bearings inspection.....	68
Wear rings inspection and replacement.....	69
Seal-chamber cover inspection and replacement.....	75
Bearing-frame inspection.....	77
Bearing fits and tolerances.....	78
Reassembly.....	79
Assemble the power end.....	79
Assemble the frame.....	84
Install the optional water-jacket cover.....	88
Install the seal-chamber cover.....	89
Install the cartridge-type mechanical seal and seal-chamber cover.....	93
Install the impeller.....	94
Install the coupling hub.....	94
Install the back pull-out assembly in the casing.....	95
Post-assembly checks.....	96
Assembly references.....	96
Troubleshooting.....	99
Operation troubleshooting.....	99
Alignment troubleshooting.....	100
Assembly troubleshooting.....	100

Parts Listings and Cross-Sectional Drawings.....101
Parts list.....101

Local ITT Contacts.....104
Regional offices.....104

Introduction and Safety

Introduction

Purpose of this manual

The purpose of this manual is to provide necessary information for:

- Installation
- Operation
- Maintenance



CAUTION:

Read this manual carefully before installing and using the product. Improper use of the product can cause personal injury and damage to property, and may void the warranty.

NOTICE:

Save this manual for future reference, and keep it readily available at the location of the unit.

Requesting other information

Special versions can be supplied with supplementary instruction leaflets. See the sales contract for any modifications or special version characteristics. For instructions, situations, or events that are not considered in this manual or in the sales documents, please contact the nearest ITT representative.

Always specify the exact product type and identification code when requesting technical information or spare parts.

Safety



WARNING:

- The operator must be aware of safety precautions to prevent physical injury.
 - Any pressure-containing device can explode, rupture, or discharge its contents if it is over-pressurized. Take all necessary measures to avoid over-pressurization.
 - Operating, installing, or maintaining the unit in any way that is not covered in this manual could cause death, serious personal injury, or damage to the equipment. This includes any modification to the equipment or use of parts not provided by ITT. If there is a question regarding the intended use of the equipment, please contact an ITT representative before proceeding.
 - This manual clearly identifies accepted methods for disassembling units. These methods must be adhered to. Trapped liquid can rapidly expand and result in a violent explosion and injury. Never apply heat to impellers, propellers, or their retaining devices to aid in their removal.
 - Do not change the service application without the approval of an authorized ITT representative.
-



CAUTION:

You must observe the instructions contained in this manual. Failure to do so could result in physical injury, damage, or delays.




Safety terminology and symbols

About safety messages

It is extremely important that you read, understand, and follow the safety messages and regulations carefully before handling the product. They are published to help prevent these hazards:

- Personal accidents and health problems
- Damage to the product
- Product malfunction

Hazard levels

Hazard level	Indication
 <p>DANGER:</p>	A hazardous situation which, if not avoided, will result in death or serious injury
 <p>WARNING:</p>	A hazardous situation which, if not avoided, could result in death or serious injury
 <p>CAUTION:</p>	A hazardous situation which, if not avoided, could result in minor or moderate injury
NOTICE:	<ul style="list-style-type: none"> • A potential situation which, if not avoided, could result in undesirable conditions • A practice not related to personal injury

Hazard categories

Hazard categories can either fall under hazard levels or let specific symbols replace the ordinary hazard level symbols.

Electrical hazards are indicated by the following specific symbol:



Electrical Hazard:

These are examples of other categories that can occur. They fall under the ordinary hazard levels and may use complementing symbols:

- Crush hazard
- Cutting hazard
- Arc flash hazard

Environmental safety

The work area

Always keep the station clean to avoid and/or discover emissions.

Waste and emissions regulations

Observe these safety regulations regarding waste and emissions:

- Appropriately dispose of all waste.
- Handle and dispose of the processed liquid in compliance with applicable environmental regulations.

- Clean up all spills in accordance with safety and environmental procedures.
 - Report all environmental emissions to the appropriate authorities.
-



WARNING:

Do NOT send the product to the ITT manufacturer if it has been contaminated by any nuclear radiation. Inform ITT so that accurate actions can take place.

Electrical installation

For electrical installation recycling requirements, consult your local electric utility.

Recycling guidelines

Always follow local laws and regulations regarding recycling.

User safety

General safety rules

These safety rules apply:

- Always keep the work area clean.
- Pay attention to the risks presented by gas and vapors in the work area.
- Avoid all electrical dangers. Pay attention to the risks of electric shock or arc flash hazards.
- Always bear in mind the risk of drowning, electrical accidents, and burn injuries.

Safety equipment

Use safety equipment according to the company regulations. Use this safety equipment within the work area:

- Helmet
 - Safety goggles, preferably with side shields
 - Protective shoes
 - Protective gloves
 - Gas mask
 - Hearing protection
 - First-aid kit
 - Safety devices
-

NOTICE:

Never operate a unit unless safety devices are installed. Also see specific information about safety devices in other chapters of this manual.

Electrical connections

Electrical connections must be made by certified electricians in compliance with all international, national, state, and local regulations. For more information about requirements, see sections dealing specifically with electrical connections.

Precautions before work

Observe these safety precautions before you work with the product or are in connection with the product:

- Provide a suitable barrier around the work area, for example, a guard rail.
 - Make sure that all safety guards are in place and secure.
 - Make sure that the equipment is properly insulated when it operates at extreme temperatures.
 - Allow all system and pump components to cool before you handle them.
 - Make sure that you have a clear path of retreat.
 - Make sure that the product cannot roll or fall over and injure people or damage property.
 - Make sure that the lifting equipment is in good condition.
 - Use a lifting harness, a safety line, and a breathing device as required.
 - Make sure that the product is thoroughly clean.
-

- Make sure that there are no poisonous gases within the work area.
- Make sure that you have quick access to a first-aid kit.
- Disconnect and lock out power before servicing.
- Check the explosion risk before you weld or use electric hand tools.

Wash the skin and eyes

Follow these procedures for chemicals or hazardous fluids that have come into contact with your eyes or your skin:

Condition	Action
Chemicals or hazardous fluids in eyes	<ol style="list-style-type: none"> 1. Hold your eyelids apart forcibly with your fingers. 2. Rinse the eyes with eyewash or running water for at least 15 minutes. 3. Seek medical attention.
Chemicals or hazardous fluids on skin	<ol style="list-style-type: none"> 1. Remove contaminated clothing. 2. Wash the skin with soap and water for at least 1 minute. 3. Seek medical attention, if necessary.

Product approval standards

Regular standards

All standard products are approved according to CSA standards in Canada and UL standards in USA. The drive unit degree of protection follows IP68. See the nameplate for maximum submersion, according to standard IEC 60529.

All electrical ratings and performance of the motors comply with IEC 600341.

Safety regulations for Ex-approved products in potentially explosive atmospheres

Description of ATEX

The ATEX directives are a specification enforced in Europe for electrical and non-electrical equipment. ATEX deals with the control of potentially explosive atmospheres and the standards of equipment and protective systems used within these atmospheres. The relevance of the ATEX requirements is not limited to Europe. You can apply these guidelines to equipment installed in any potentially explosive atmosphere.

Guidelines for compliance

Compliance is only fulfilled when the pump is operated within its intended use, for example within its intended hydraulic range. The conditions of the service must not be changed without approval of an authorized ITT representative. When installing or maintaining explosion-proof pumps, follow these guidelines:

- Always install ATEX-approved equipment in compliance with the directive and applicable standards (IEC/EN 60079–14).
- Do not install explosion proof products in locations that are classified as hazardous in the national electric code, ANSI/NFPA 70–2005.



WARNING:

This manual clearly identifies accepted methods for disassembling units. These methods must be adhered to. Trapped liquid can rapidly expand and result in a violent explosion and injury. Never apply heat to impellers, propellers, or their retaining devices to aid in their removal.

If there are any questions regarding these requirements, the intended use, or if the equipment requires modification, contact an ITT representative before you proceed.

Personnel requirements

ITT disclaims all responsibility for work done by untrained and unauthorized personnel.

These are the personnel requirements for Ex-approved products in potentially explosive atmospheres:

- All work on the product must be carried out by certified electricians and IIT-authorized mechanics. Special rules apply to installations in explosive atmospheres.
- All users must know about the risks of electric current and the chemical and physical characteristics of the gas and/or vapor present in hazardous areas.
- Any maintenance for Ex-approved products must conform to international and national standards (for example IEC/EN 60079-17).

Product and product handling requirements

These are the product and product handling requirements for Ex-approved products in potentially explosive atmospheres:

- Only use the product in accordance with the approved motor data stated on the nameplates.
- The Ex-approved product must never run dry during normal operation. Dry running during service and inspection is only permitted outside the classified area.
- Never start a pump without the proper priming.
- Before you start working with the product, make sure that the product and the control panel are isolated from the power supply and the control circuit, so they cannot be energized.
- Do not open the product while it is energized or in an explosive gas atmosphere.
- Make sure that thermal contacts are connected to a protection circuit according to the approval classification of the product.
- Intrinsically safe circuits are normally required for the automatic level-control system by the level regulator if mounted in zone 0.
- The yield stress of fasteners must be in accordance with the approval drawing and the product specification.
- Do not modify the equipment without approval from an authorized IIT representative.
- Only use parts that have been provided by an authorized IIT representative.

Equipment for monitoring

For additional safety, use condition-monitoring devices. Condition-monitoring devices include but are not limited to these devices:

- Pressure gauges
- Flow meters
- Level indicators
- Motor load readings
- Temperature detectors
- Bearing monitors
- Leak detectors
- PumpSmart control system

Product warranty

Coverage

IIT undertakes to remedy faults in products from IIT under these conditions:

- The faults are due to defects in design, materials, or workmanship.
- The faults are reported to an IIT representative within the warranty period.
- The product is used only under the conditions described in this manual.
- The monitoring equipment incorporated in the product is correctly connected and in use.
- All service and repair work is done by IIT-authorized personnel.
- Genuine IIT parts are used.
- Only Ex-approved spare parts and accessories authorized by IIT are used in Ex-approved products.

Limitations

The warranty does not cover faults caused by these situations:

- Deficient maintenance
- Improper installation
- Modifications or changes to the product and installation made without consulting ITT
- Incorrectly executed repair work
- Normal wear and tear

ITT assumes no liability for these situations:

- Bodily injuries
- Material damages
- Economic losses

Warranty claim

ITT products are high-quality products with expected reliable operation and long life. However, should the need arise for a warranty claim, then contact your ITT representative.

Transportation and Storage

Inspect the delivery

Inspect the package

1. Inspect the package for damaged or missing items upon delivery.
2. Note any damaged or missing items on the receipt and freight bill.
3. File a claim with the shipping company if anything is out of order.
If the product has been picked up at a distributor, make a claim directly to the distributor.

Inspect the unit

1. Remove packing materials from the product.
Dispose of all packing materials in accordance with local regulations.
2. Inspect the product to determine if any parts have been damaged or are missing.
3. If applicable, unfasten the product by removing any screws, bolts, or straps.
For your personal safety, be careful when you handle nails and straps.
4. Contact your sales representative if anything is out of order.

Transportation guidelines

Pump handling



WARNING:

- Make sure that the unit cannot roll or fall over and injure people or damage property.
- These pumps might use carbon or ceramic silicon carbide components. Do not drop the pump or subject it to shock loads as this can damage the internal ceramic components.

NOTICE: Use a forklift truck or an overhead crane with sufficient capacity to move the pallet with the pump unit on top. Failure to do so can result in equipment damage.

Lifting methods



WARNING:

- Assembled units and their components are heavy. Failure to properly lift and support this equipment can result in serious physical injury and/or equipment damage. Lift equipment only at the specifically identified lifting points. Lifting devices such as eyebolts, slings, and spreaders must be rated, selected, and used for the entire load being lifted.
- Crush hazard. The unit and the components can be heavy. Use proper lifting methods and wear steel-toed shoes at all times.
- Do not attach sling ropes to shaft ends.

Table 1: Methods

Pump type	Lifting method
A bare pump without lifting handles	Use a suitable sling attached properly to solid points like the casing, the flanges, or the frames.
A bare pump with lifting handles	Lift the pump by the handles.
A base-mounted pump	Use slings under the pump casing and the drive unit, or under the base rails.

Examples




Figure 1: Example of a proper lifting method




Figure 2: Example of a proper lifting method




Figure 3: Example of a proper lifting method

Storage guidelines

Pump storage requirements

Storage requirements depend on the amount of time that you store the unit. The normal packaging is designed only to protect the unit during shipping.

Length of time in storage	Storage requirements
Upon receipt/short-term (less than six months)	<ul style="list-style-type: none"> • Store in a covered and dry location. • Store the unit free from dirt and vibrations.
Long-term (more than six months)	<ul style="list-style-type: none"> • Store in a covered and dry location. • Store the unit free from heat, dirt, and vibrations. • Rotate the shaft by hand several times at least every three months.

Treat bearing and machined surfaces so that they are well preserved. Refer to drive unit and coupling manufacturers for their long-term storage procedures.

You can purchase long-term storage treatment with the initial unit order or you can purchase it and apply it after the units are already in the field. Contact your local IIT sales representative.

Frostproofing

Table 2: Situations when the pump is or is not frostproof

Situation	Condition
Operating	The pump is frostproof.
Immersed in a liquid	The pump is frostproof.
Lifted out of a liquid into a temperature below freezing	The impeller might freeze.

Product Description

General description 3700

Product description

The Model 3700 is a high-pressure, high-temperature centrifugal pump that meets the requirements of API Standard 610 11th Edition (ISO 13709).




Figure 4: 3700 pump

Casing

The casing is a centerline-mounted design. The gasket is fully confined.

The standard flanges are ANSI Class 300 raised-face serrated. The following flanges are also available:

- ANSI Class 300 flat-face serrated
- ANSI Class 300 ring joint
- ANSI Class 600 flat-face serrated
- ANSI Class 600 ring joint

Impeller

The impeller is fully enclosed and key driven by the shaft. One of the following parts prevents axial movement:

- Impeller bolt with a lockwasher
- Impeller nut with a locking set screw

Seal-chamber cover

The seal-chamber cover meets API 682 3rd Edition dimensions for improved performance of mechanical seals.

Power end

The power end has the following characteristics:

- Standard ring oil-lubricated bearings
- Labyrinth seals on the power end
- Optional pure and purge oil mist lubrication (some machining is required to convert from ring oil lubrication to oil mist)

Shaft

The standard shaft is machined and ground to comply with API 610 11th Edition (ISO 13709) criteria.

Bearings

Bearing type	Characteristics
Inboard (radial)	<ul style="list-style-type: none"> • Consists of a single-row deep-groove ball bearing • Carries only radial load • Freely floats axially in the frame
Outboard (thrust)	<ul style="list-style-type: none"> • Consists of a duplex-angular contact bearing, which uses a pair of single-row angular contact ball bearings mounted back-to-back • Shouldered and locked to the shaft • Retained in the bearing frame to enable it to carry radial and thrust loads

All fits are precision-machined to industry standards.

Baseplate

The fabricated steel baseplate supports the pump, driver, and accessories in accordance with API-610 11th Edition (ISO 13709) requirements.

Direction of rotation

The shaft rotates counterclockwise when viewed from the drive end.

Nameplate information

Important information for ordering

Every pump has nameplates that provide information about the pump. The nameplates are located on the casing and the bearing frame.

When you order spare parts, identify this pump information:


- Model
- Size
- Serial number
- Item numbers of the required parts

Refer to the nameplate on the pump casing for most of the information. See Parts List for item numbers.

Nameplate types

Nameplate	Description
Pump casing	Provides information about the hydraulic characteristics of the pump. The formula for the pump size is: Discharge x Suction - Nominal Maximum Impeller Diameter in inches. (Example: 2x3-8)
ATEX	If applicable, your pump unit might have an ATEX nameplate affixed to the pump, the baseplate, or the discharge head. The nameplate provides information about the ATEX specifications of this pump.
IECEX	If applicable, your pump unit might have the following IECEX nameplate affixed to the pump and/or baseplate. The nameplate provides information about the IECEX specifications of this pump.


Nameplate on the pump casing using English units


GOULDS PUMPS, INC.
 CAUTION: AFTER STARTING DO NOT
 OPERATE AGAINST CLOSED VALVE.
 SENECA FALLS, N.Y. MADE IN USA

MODEL SIZE
 G P M HEAD-FT. RPM
 I.B.BRG. HYDRO-PRESS
 LB/IN² @ 70 ° F
 O.B.BRG.
 CONST./ITEM NO.
 S/N

Nameplate field	Explanation
MODEL	Pump model
SIZE	Size of the pump
GPM	Rated pump flow, in gallons per minute
HEAD-FT	Rated pump head, in feet
RPM	Rated pump speed, in revolutions per minute
I.B. BRG.	Inboard bearing designator
HYDRO-PRESS	Hydrostatic pressure at 70°F, in pounds per square inch
O.B. BRG.	Outboard bearing designator
MAX. WORKING PRESS	Maximum working pressure, in pounds per square inch
S/N	Serial number of the pump
CONT./ITEM NO.	Material of which pump is constructed and the customer item number

Nameplate on the pump casing using metric units



Nameplate field	Explanation
MODEL	Pump model
SIZE	Size of the pump
M ³ /HR	Rated pump flow, in cubic meters per hour
HEAD-M	Rated pump head, in meters
RPM	Rated pump speed, in revolutions per minute
I.B. BRG.	Inboard bearing designator
HYDRO-PRESS	Hydrostatic pressure at 20°C, in kilograms per square centimeter
O.B. BRG.	Outboard bearing designator
MAX. WORKING PRESS	Maximum working pressure, in kilograms per square centimeter
S/N	Serial number of the pump
CONT./ITEM NO.	Material of which the pump is constructed and the customer item number

ATEX nameplate



Nameplate field	Explanation
II	Group 2
2	Category 2
G/D	Pump can be used when gas and dust are present
T4	Temperature class

Table 3: Temperature class definitions

Code	Maximum permissible surface temperature in °F (°C)	Minimum permissible surface temperature in °F (°C)
T1	842 (450)	700 (372)

Code	Maximum permissible surface temperature in °F (°C)	Minimum permissible surface temperature in °F (°C)
T2	572 (300)	530 (277)
T3	392 (200)	350 (177)
T4	275 (135)	235 (113)
T5	212 (100)	Option not available
T6	185 (85)	Option not available

NOTICE: Make sure that the code classifications on the pump are compatible with the specific environment in which you plan to install the equipment. If they are not compatible, do not operate the equipment and contact your ITT representative before you proceed.

Installation

Preinstallation

Precautions


WARNING:

- When installing in a potentially explosive environment, make sure that the motor is properly certified.
- You must earth (ground) all electrical equipment. This applies to the pump equipment, the driver, and any monitoring equipment. Test the earth (ground) lead to verify that it is connected correctly.

NOTICE: Supervision by an authorized IIT representative is recommended to ensure proper installation. Failure to do so may result in equipment damage or decreased performance.

Pump location guidelines


WARNING:

Assembled units and their components are heavy. Failure to properly lift and support this equipment can result in serious physical injury and/or equipment damage. Lift equipment only at the specifically identified lifting points. Lifting devices such as eyebolts, slings, and spreaders must be rated, selected, and used for the entire load being lifted.


Guideline	Explanation/comment
Keep the pump as close to the liquid source as practically possible.	This minimizes the friction loss and keeps the suction piping as short as possible.
Make sure that the space around the pump is sufficient.	This facilitates ventilation, inspection, maintenance, and service.
If you require lifting equipment such as a hoist or tackle, make sure that there is enough space above the pump.	This makes it easier to properly use the lifting equipment and safely remove and relocate the components to a safe location.
Protect the unit from weather and water damage due to rain, flooding, and freezing temperatures.	This is applicable if nothing else is specified.
Do not install and operate the equipment in closed systems unless the system is constructed with properly-sized safety devices and control devices.	Acceptable devices: <ul style="list-style-type: none"> • Pressure relief valves • Compression tanks • Pressure controls • Temperature controls • Flow controls If the system does not include these devices, consult the engineer or architect in charge before you operate the pump.
Take into consideration the occurrence of unwanted noise and vibration.	The best pump location for noise and vibration absorption is on a concrete floor with subsoil underneath.
If the pump location is overhead, undertake special precautions to reduce possible noise transmission.	Consider a consultation with a noise specialist.

Foundation requirements

Requirements


- The foundation must be able to absorb any type of vibration and form a permanent, rigid support for the unit.
- The location and size of the foundation bolt holes must match those shown on the assembly drawing provided with the pump data package.
- The foundation must weigh between two and three times the weight of the pump.
- Provide a flat, substantial concrete foundation in order to prevent strain and distortion when you tighten the foundation bolts.
- Sleeve-type and J-type foundation bolts are most commonly used. Both designs allow movement for the final bolt adjustment.

Sleeve-type bolts



1. Baseplate
2. Shims or wedges
3. Foundation
4. Sleeve
5. Dam
6. Bolt

J-type bolts



1. Baseplate
2. Shims or wedges
3. Foundation
4. Dam
5. Bolt

Baseplate-mounting procedures

Prepare the baseplate for mounting

This procedure assumes you have a basic knowledge of baseplate and foundation design and installation methods. Follow industry-standard procedures, such as API RP 686/ PIP REIE 686, or this procedure before you grout the baseplate.

1. Make sure that all baseplate surfaces that will contact grout are free from contamination such as rust, oil, and grime.
2. Thoroughly clean all baseplate surfaces that will come in contact with grout.

Make sure to use a cleaner that will not leave residue.

NOTICE:

You may need to sandblast the surfaces of a baseplate that come in contact with grout, and then coat those surfaces with a primer that is grout-compatible. Make sure to remove all equipment before sandblasting.

3. Make sure that all machined surfaces are free from burrs, rust, paint, or any other type of contamination.

If necessary, use a honing stone to remove burrs.

Prepare the foundation for mounting

1. Chip the top of the foundation to a minimum of 1.0 in. (25.0 mm) in order to remove porous or low-strength concrete.

If you use a pneumatic hammer, make sure that it does not contaminate the surface with oil or other moisture.

NOTICE: Do not chip the foundation using heavy tools such as jackhammers. This can damage the structural integrity of the foundation.

2. Remove water or debris from the foundation bolt holes or sleeves.
3. If the baseplate uses sleeve-type bolts, then fill the sleeves with a non-binding, moldable material. Seal the sleeves in order to prevent the grout from entering.
4. Coat the exposed portion of the anchor bolts with a non-bonding compound such as paste wax in order to prevent the grout from adhering to the anchor bolts.
Do not use oils or liquid wax.
5. If recommended by the grout manufacturer, coat the foundation surface with a compatible primer.


Install the baseplate using jackscrews

Tools required:

- Anti-seize compound
- Jackscrews
- Bar stock
- Two machinist's levels

This procedure is applicable to the feature-fabricated steel baseplate and the advantage base baseplate.

1. Apply an anti-seize compound on the jackscrews.
The compound makes it easier to remove the screws after you grout.
2. Lower the baseplate carefully onto the foundation bolts and perform these steps:
 - a) Cut the plates from the bar stock and chamfer the edges of the plates in order to reduce stress concentrations.
 - b) Put the plates between the jackscrews and the foundation surface.
 - c) Use the four jackscrews in the corners in order to raise the baseplate above the foundation.
Make sure that the distance between the baseplate and the foundation surface is between 0.75 in. (19 mm) and 1.50 in. (38 mm).
 - d) Make sure that the center jackscrews do not touch the foundation surface yet.



1. Jackscrew
2. Baseplate
3. Foundation
4. Plate

3. Level the driver mounting pads:

NOTICE: Remove all dirt from the mounting pads in order to make sure that you achieve the correct leveling. Failure to do so can result in equipment damage or decreased performance.

- a) Put one machinist's level lengthwise on one of the two pads.
- b) Put the other machinist's level across the ends of the two pads.
- c) Level the pads by adjusting the four jackscrews in the corners.

Make sure that the machinist's level readings are as close to zero as possible, both lengthwise and across.

4. Turn the center jackscrews down so that they rest on their plates on the foundation surface.
5. Level the pump mounting pads:

NOTICE: Remove all dirt from the mounting pads in order to make sure that you achieve the correct leveling. Failure to do so can result in equipment damage or decreased performance.

- a) Put one machinist's level lengthwise on one of the two pads.
- b) Put the other level across the center of the two pads.
- c) Level the pads by adjusting the four jackscrews in the corners.

Make sure that the machinist's level readings are as close to zero as possible, both lengthwise and across.

6. Hand-tighten the nuts for the foundation bolts.
7. Check that the driver's mounting pads are level and adjust the jackscrews and the foundation bolts if necessary.

The correct level measurement is a maximum of 0.002 in./ft (0.0167 mm/m).

The maximum variation from one side of the baseplate to the other is 0.015 in. (0.38 mm).

Install the pump, driver, and coupling

1. Mount and fasten the pump on the baseplate. Use applicable bolts.
2. Mount the driver on the baseplate. Use applicable bolts and hand tighten.
3. Install the coupling.

See the installation instructions from the coupling manufacturer.

Pump-to-driver alignment

Precautions



WARNING:

- Follow shaft alignment procedures in order to prevent catastrophic failure of drive components or unintended contact of rotating parts. Follow the coupling installation and operation procedures from the coupling manufacturer.
- Always disconnect and lock out power to the driver before you perform any installation or maintenance tasks. Failure to disconnect and lock out driver power will result in serious physical injury.

NOTICE: Proper alignment is the responsibility of the installer and the user of the unit. Check the alignment of frame-mounted units before you operate the unit. Failure to do so can result in equipment damage or decreased performance.

Alignment methods

Three common alignment methods are used:

- Dial indicator
- Reverse dial indicator
- Laser

Follow the instructions from the equipment manufacturer when you use the reverse dial indicator or laser methods. Detailed instructions for using the dial indicator method are contained in this chapter.

Alignment checks

When to perform alignment checks

You must perform alignment checks under these circumstances:

- The process temperature changes.
- The piping changes.
- The pump has been serviced.

Types of alignment checks

Type of check	When it is used
Initial alignment (cold alignment) check	Prior to operation when the pump and the driver are at ambient temperature.
Final alignment (hot alignment) check	After operation when the pump and the driver are at operating temperature.

Initial alignment (cold alignment) checks

When	Why
Before you grout the baseplate	This ensures that alignment can be accomplished.
After you grout the baseplate	This ensures that no changes have occurred during the grouting process.
After you connect the piping	This ensures that pipe strains have not altered the alignment. If changes have occurred, you must alter the piping to remove pipe strains on the pump flanges.

Final alignment (hot alignment) checks

When	Why
After the first run	This ensures correct alignment when both the pump and the driver are at operating temperature.
Periodically	This follows the plant operating procedures.

Permitted indicator values for alignment checks

NOTICE: The specified permitted reading values are valid only at operating temperature. For cold settings, other values are permitted. You must use the correct tolerances. Failure to do so can result in misalignment and reduced pump reliability.

IMPORTANT

- For electric motors, the motor shaft initial (cold) parallel vertical alignment setting should be 0.002 to 0.004 in. (0.05 to 0.10 mm) lower than the pump shaft.
- For other drivers such as turbines and engines, follow the driver manufacturer's recommendations.

When dial indicators are used to check the final alignment, the pump and drive unit are correctly aligned when these conditions are true:

- The total indicator runout is a maximum of 0.002 in. (0.05 mm) at operating temperature.
- The tolerance of the indicator is 0.0005 in./in. (0.0127 mm/mm) of indicator separation at operating temperature.


Alignment measurement guidelines

Guideline	Explanation
Rotate the pump coupling half and the driver coupling half together so that the indicator rods have contact with the same points on the driver coupling half.	This prevents incorrect measurement.
Move or shim only the driver in order to make adjustments.	This prevents strain on the piping installations.
Make sure that the hold-down bolts for the driver feet are tight when you take indicator measurements.	This keeps the driver stationary since movement causes incorrect measurement.
Make sure that the hold-down bolts for the driver feet are loose before you make alignment corrections.	This makes it possible to move the driver when you make alignment corrections.
Check the alignment again after any mechanical adjustments.	This corrects any misalignments that an adjustment may have caused.

Attach the dial indicators for alignment

You must have two dial indicators in order to complete this procedure.

1. Attach two dial indicators on the pump coupling half (X):
 - a) Attach one indicator (P) so that the indicator rod comes into contact with the perimeter of the driver coupling half (Y).
This indicator is used to measure parallel misalignment.
 - b) Attach the other indicator (A) so that the indicator rod comes into contact with the inner end of the driver coupling half.
This indicator is used to measure angular misalignment.




2. Rotate the pump coupling half (X) in order to check that the indicators are in contact with the driver coupling half (Y) but do not bottom out.
3. Adjust the indicators if necessary.

Pump-to-driver alignment instructions

Perform angular alignment for a vertical correction

1. Set the angular alignment indicator to zero at the top-center position (12 o'clock) of the driver coupling half (Y).
2. Rotate the indicator to the bottom-center position (6 o'clock).
3. Record the indicator reading.

When the reading value is...	Then...
Negative	The coupling halves are farther apart at the bottom than at the top. Perform one of these steps: <ul style="list-style-type: none"> • Add shims in order to raise the feet of the driver at the shaft end. • Remove shims in order to lower the feet of the driver at the other end.
Positive	The coupling halves are closer at the bottom than at the top. Perform one of these steps: <ul style="list-style-type: none"> • Remove shims in order to lower the feet of the driver at the shaft end. • Add shims in order to raise the feet of the driver at the other end.



1. Shims

Figure 5: Example of incorrect vertical alignment (side view)

4. Repeat the previous steps until the permitted reading value is achieved.

Perform angular alignment for a horizontal correction

1. Set the angular alignment indicator (A) to zero on left side of the driver coupling half (Y), 90° from the top-center position (9 o'clock).
2. Rotate the indicator through the top-center position to the right side, 180° from the start position (3 o'clock).
3. Record the indicator reading.

When the reading value is...	Then...
Negative	The coupling halves are farther apart on the right side than the left. Perform one of these steps: <ul style="list-style-type: none"> • Slide the shaft end of the driver to the left. • Slide the opposite end to the right.
Positive	The coupling halves are closer together on the right side than the left. Perform one of these steps: <ul style="list-style-type: none"> • Slide the shaft end of the driver to the right. • Slide the opposite end to the left.




Figure 6: Example of incorrect horizontal alignment (top view)

4. Repeat the previous steps until the permitted reading value is achieved.

Perform parallel alignment for a vertical correction

Before you start this procedure, make sure that the dial indicators are correctly set up.


A unit is in parallel alignment when the parallel indicator (P) does not vary by more than 0.002 in. (0.05 mm) as measured at four points 90° apart at the operating temperature.

1. Set the parallel alignment indicator (P) to zero at the top-center position (12 o'clock) of the driver coupling half (Y).
2. Rotate the indicator to the bottom-center position (6 o'clock).
3. Record the indicator reading.

When the reading value is...	Then...
Negative	The pump coupling half (X) is lower than the driver coupling half (Y). Remove shims of a thickness equal to half of the indicator reading value under each driver foot.
Positive	The pump coupling half (X) is higher than the driver coupling half (Y). Add shims of a thickness equal to half of the indicator reading value to each driver foot.

NOTICE:

You must use an equal amount of shims with each driver foot to prevent misalignment. Failure to do so can result in equipment damage or decreased performance.



1. Shims

Figure 7: Example of incorrect vertical alignment (side view)

4. Repeat the previous steps until the permitted reading value is achieved.

Perform parallel alignment for a horizontal correction

A unit is in parallel alignment when the parallel indicator (P) does not vary by more than 0.002 in. (0.05 mm) as measured at four points 90° apart at the operating temperature.

1. Set the parallel alignment indicator (P) to zero on the left side of the driver coupling half (Y), 90° from the top-center position (9 o'clock).
2. Rotate the indicator through the top-center position to the right side, 180° from the start position (3 o'clock).
3. Record the indicator reading.

When the reading value is...	Then...
Negative	The driver coupling half (Y) is to the left of the pump coupling half (X).
Positive	The driver coupling half (Y) is to the right of the pump coupling half (X).

4. Slide the driver carefully in the appropriate direction.

NOTICE: Make sure to slide the driver evenly. Failure to do so can negatively affect horizontal angular correction.




Figure 8: Example of incorrect horizontal alignment (top view)

5. Repeat the previous steps until the permitted reading value is achieved.

Perform complete alignment for a vertical correction

A unit is in complete alignment when both the angular indicator (A) and the parallel indicator (P) do not vary by more than 0.002 in. (0.05 mm) as measured at four points 90° apart.

1. Set the angular and parallel dial indicators to zero at the top-center position (12 o'clock) of the driver coupling half (Y).
2. Rotate the indicators to the bottom-center position (6 o'clock).
3. Record the indicator readings.
4. Make corrections according to the separate instructions for angular and parallel alignment until you obtain the permitted reading values.

Perform complete alignment for a horizontal correction

A unit is in complete alignment when both the angular indicator (A) and the parallel indicator (P) do not vary by more than 0.002 in. (0.05 mm) as measured at four points 90° apart.

1. Set the angular and parallel dial indicators to zero at the left side of the driver coupling half (Y), 90° from the top-center position (9 o'clock).
2. Rotate the indicators through the top-center position to the right side, 180° from the start position (3 o'clock).
3. Record the indicator readings.
4. Make corrections according to the separate instructions for angular and parallel alignment until you obtain the permitted reading values.

Grout the baseplate

Required equipment:


- Cleaners: Do not use an oil-based cleaner because the grout will not bond to it. See the instructions provided by the grout manufacturer.
- Grout: Non-shrink grout is recommended.

NOTICE: It is assumed that the installer who grouts the baseplate has knowledge of acceptable methods. More detailed procedures are described in various publications, including API Standard 610, 11th Edition, Appendix L; API RP 686, Chapter 5; and other industry standards.


1. Clean all the areas of the baseplate that will come into contact with the grout.
2. Build a dam around the foundation.
3. Thoroughly wet the foundation that will come into contact with the grout.
4. Pour grout through the grout hole into the baseplate up to the level of the dam.

When you pour the grout, remove air bubbles from it by using one of these methods:

- Puddle with a vibrator.
 - Pump the grout into place.
5. Allow the grout to set.



1. Baseplate
 2. Shims or wedges
 3. Grout
 4. Foundation
 5. Sleeve
 6. Dam
 7. Bolt
6. Fill the remainder of the baseplate with grout, and allow the grout to set for at least 48 hours.



- 1. Baseplate
- 2. Grout
- 3. Foundation
- 4. Dam
- 5. Bolt

- 7. Remove the leveling jackscrews after the grout hardens in order to remove any stress points.
- 8. Tighten the foundation bolts.

Piping checklists

General piping checklist

Precautions



CAUTION:

- Never draw piping into place by using force at the flanged connections of the pump. This can impose dangerous strains on the unit and cause misalignment between the pump and driver. Pipe strain adversely affects the operation of the pump, which results in physical injury and damage to the equipment.
- Vary the capacity with the regulating valve in the discharge line. Never throttle the flow from the suction side. This action can result in decreased performance, unexpected heat generation, and equipment damage.

NOTICE:

Flange loads from the piping system, including those from the thermal expansion of the piping, must not exceed the limits of the pump. Casing deformation can result in contact with rotating parts, which can result in excess heat generation, sparks, and premature failure.

Piping guidelines

Guidelines for piping are given in the Hydraulic Institute Standards available from the Hydraulic Institute at 9 Sylvan Way, Parsippany, NJ 07054-3802. You must review this document before you install the pump.

Checklist


Check	Explanation/comment	Checked
Check that all piping is supported independently of, and lined up naturally with, the pump flange. See Alignment criteria for pump flanges.	This helps to prevent: <ul style="list-style-type: none"> • Strain on the pump • Misalignment between the pump and the drive unit • Wear on the pump bearings and the coupling • Wear on the pump bearings, seal, and shafting 	
Keep the piping as short as possible.	This helps to minimize friction losses.	
Check that only necessary fittings are used.	This helps to minimize friction losses.	

Check	Explanation/comment	Checked
Do not connect the piping to the pump until: <ul style="list-style-type: none"> • The grout for the baseplate or sub-base becomes hard. • The hold-down bolts for the pump and the driver are tightened. 	—	
Make sure that all the piping joints and fittings are airtight.	This prevents air from entering the piping system or leaks that occur during operation.	
If the pump handles corrosive fluids, make sure that the piping allows you to flush out the liquid before you remove the pump.	—	
If the pump handles liquids at elevated temperatures, make sure that the expansion loops and joints are properly installed.	This helps to prevent misalignment due to linear expansion of the piping.	

Alignment criteria for pump flanges

Type	Criteria
Axial	The flange gasket thickness is ± 0.03 in. (0.8 mm).
Parallel	Align the flange to be within 0.001 in./in. to 0.03 in./in. maximum (0.025 mm/mm to 0.8 mm/mm) of the flange diameter.
Concentric	You can easily install the flange bolts by hand.

Example: Installation for expansion



Suction-piping checklist

Performance curve reference

Net positive suction head available ($NPSH_A$) must always exceed $NPSH$ required ($NPSH_R$) as shown on the published performance curve of the pump.

Suction-piping checks

Check	Explanation/comment	Checked
Check that the distance between the inlet flange of the pump and the closest elbow is at least five pipe diameters.	This minimizes the risk of cavitation in the suction inlet of the pump due to turbulence. See the Example sections for illustrations.	
Check that elbows in general do not have sharp bends.	See the Example sections for illustrations.	
Check that the suction piping is one or two sizes larger than the suction inlet of the pump. Install an eccentric reducer between the pump inlet and the suction piping.	The suction piping must never have a smaller diameter than the suction inlet of the pump. See the Example sections for illustrations.	
Check that the eccentric reducer at the suction flange of the pump has the following properties: <ul style="list-style-type: none"> • Sloping side down • Horizontal side at the top 	See the example illustrations.	
If suction strainers or suction bells are used, check that they are at least three times the area of the suction piping.	Suction strainers help to prevent clogging. Mesh holes with a minimum diameter of 1/16 in. (1.6 mm) are recommended.	
If more than one pump operates from the same liquid source, check that separate suction-piping lines are used for each pump.	This recommendation helps you to achieve a higher pump performance.	
If necessary, make sure that the suction piping includes a drain valve and that it is correctly installed.	—	

Liquid source below the pump


Check	Explanation/comment	Checked
Make sure that the suction piping is free from air pockets.	This helps to prevent the occurrence of air and cavitation in the pump inlet.	
Check that the suction piping slopes upwards from the liquid source to the pump inlet.	—	
If the pump is not self-priming, check that a device for priming the pump is installed.	Use a foot valve with a diameter that is at least equivalent to the diameter of the suction piping.	

Liquid source above the pump



Check	Explanation/comment	Checked
Check that an isolation valve is installed in the suction piping at a distance of at least two times the pipe diameter from the suction inlet.	This permits you to close the line during pump inspection and maintenance. Do not use the isolation valve to throttle the pump. Throttling can cause these problems: <ul style="list-style-type: none"> • Loss of priming • Excessive temperatures • Damage to the pump • Voiding the warranty 	

Check	Explanation/comment	Checked
Make sure that the suction piping is free from air pockets.	This helps to prevent the occurrence of air and cavitation in the pump inlet.	
Check that the piping is level or slopes downward from the liquid source.	—	
Make sure that no part of the suction piping extends below the suction flange of the pump.	—	
Make sure that the suction piping is adequately submerged below the surface of the liquid source.	This prevents air from entering the pump through a suction vortex.	

Example: Elbow close to the pump suction inlet

Correct	Incorrect
The correct distance between the inlet flange of the pump and the closest elbow must be at least five pipe diameters.	

Example: Suction piping equipment


Correct	Incorrect
 <ol style="list-style-type: none"> 1. Suction pipe sloping upwards from liquid source 2. Long-radius elbow 3. Strainer 4. Foot valve 5. Eccentric reducer with a level top 	 <ol style="list-style-type: none"> 1. Air pocket, because the eccentric reducer is not used and because the suction piping does not slope gradually upward from the liquid source

Discharge piping checklist

Checklist

Check	Explanation/comment	Checked
Check that an isolation valve is installed in the discharge line.	The isolation valve is required for: <ul style="list-style-type: none"> • Priming • Regulation of flow • Inspection and maintenance of the pump See Example: Discharge piping equipment for illustrations.	
Check that a check valve is installed in the discharge line, between the isolation valve and the pump discharge outlet.	The location between the isolation valve and the pump allows inspection of the check valve. The check valve prevents damage to the pump and seal due to the back flow through the pump, when the drive unit is shut off. It is also used to restrain the liquid flow. See Example: Discharge piping equipment for illustrations.	
If increasers are used, check that they are installed between the pump and the check valve.	See Example: Discharge piping equipment for illustrations.	
If quick-closing valves are installed in the system, check that cushioning devices are used.	This protects the pump from surges and water hammer.	

Example: Discharge piping equipment



Bypass-piping considerations

When to use a bypass line

Provide a bypass line for systems that require operation at reduced flows for prolonged periods. Connect a bypass line from the discharge side (before any valves) to the source of suction.

When to install a minimum-flow orifice

You can size and install a minimum-flow orifice in a bypass line in order to prevent bypassing excessive flows. Consult your ITT representative for assistance in sizing a minimum-flow orifice.

When a minimum-flow orifice is unavailable

Consider an automatic recirculation control valve or solenoid-operated valve if a constant bypass (minimum-flow orifice) is not possible.

Auxiliary-piping checklist

Precautions



WARNING:

- Cooling systems such as those for bearing lubrication and mechanical-seal systems must be operating properly to prevent excess heat generation, sparks, and premature failure.
- Sealing systems that are not self-purging or self-venting, such as plan 23, require manual venting prior to operation. Failure to do so will result in excess heat generation and seal failure.

NOTICE:

The mechanical seal must have an appropriate seal-flush system. Otherwise, excess heat generation and seal failure can occur.

When to install

You may need to install auxiliary piping for bearing cooling, seal-chamber cover cooling, mechanical seal flush, or other special features supplied with the pump. Consult the pump data sheet for specific auxiliary piping recommendations.

Checklist

Check	Explanation/comment	Checked
Check that the minimum flow for each component is 1 gpm (4 lpm). If the bearing and seal chamber cover cooling are provided, then the auxiliary piping must flow at 2 gpm (8 lpm).	Make sure that these guidelines are followed.	
Check that the cooling water pressure does not exceed 100 psig (7.0 kg/cm ²).	Make sure that these guidelines are followed.	

Final piping checklist

Check	Explanation/comment	Checked
Check that the shaft rotates smoothly.	Rotate the shaft by hand. Make sure there is no rubbing that can lead to excess heat generation or sparks.	
Re-check the alignment to make sure that pipe strain has not caused any misalignment.	If pipe strain exists, then correct the piping.	

Commissioning, Startup, Operation, and Shutdown

Preparation for startup



WARNING:

- Failure to follow these precautions before you start the unit will lead to serious personal injury and equipment failure.
 - Never operate the pump below the minimum rated flow, when dry, or without prime.
 - Do not operate the pump below the minimum rated flows or with the suction or discharge valves closed. These conditions can create an explosive hazard due to vaporization of pumped fluid and can quickly lead to pump failure and physical injury.
 - Foreign objects in the pumped liquid or piping system can block the flow and cause excess heat generation, sparks and premature failure. Make sure that the pump and systems are free of foreign objects before and during operation.
 - A build-up of gases within the pump, sealing system, or process piping system may result in an explosive environment. Make sure the process piping system, pump and sealing system are properly vented prior to operation.
 - Sealing systems that are not self-purging or self-venting, such as plan 23, require manual venting prior to operation. Failure to do so will result in excess heat generation and seal failure.
 - Never operate the pump without the coupling guard correctly installed.
 - Always disconnect and lock out power to the driver before you perform any installation or maintenance tasks. Failure to disconnect and lock out driver power will result in serious physical injury.
 - Operating the pump in reverse rotation can result in the contact of metal parts, heat generation, and breach of containment.
-

Precautions

NOTICE:

- Verify the driver settings before you start any pump.
 - Make sure that the temperature change does not exceed 35°F (19°C) per minute.
 - The maximum allowable temperature change for an abnormal transient event such as thermal shock is 400°F (205°C).
-

You must follow these precautions before you start the pump:


- Flush and clean the system thoroughly to remove dirt or debris in the pipe system in order to prevent premature failure at initial startup.
- Bring variable-speed drivers to the rated speed as quickly as possible.
- Run a new or rebuilt pump at a speed that provides enough flow to flush and cool the close-running surfaces of the stuffing-box bushing.
- If temperatures of the pumped fluid will exceed 200°F (93°C), then warm up the pump prior to operation. Circulate a small amount of fluid through the pump until the casing temperature is within 100°F (38°C) of the fluid temperature.

At initial startup, do not adjust the variable-speed drivers or check for speed governor or over-speed trip settings while the variable-speed driver is coupled to the pump. If the settings have not been verified, then uncouple the unit and refer to instructions supplied by the driver manufacturer.

Remove the coupling guard

1. Remove the nut, bolt, and washers from the slotted hole in the center of the coupling guard.
-

2. Slide the driver half of the coupling guard toward the pump.
3. Remove the nut, bolt, and washers from the driver half of the coupling guard.
4. Remove the driver-side end plate.
5. Remove the driver half of the coupling guard:
 - a) Slightly spread the bottom apart.
 - b) Lift upwards.
6. Remove the remaining nut, bolt, and washers from the pump half of the coupling guard.
It is not necessary to remove the end plate from the pump side of the bearing housing. You can access the bearing-housing tap bolts without removing this end plate if maintenance of internal pump parts is necessary.
7. Remove the pump half of the coupling guard:
 - a) Slightly spread the bottom apart.
 - b) Lift upwards.



1. Annular groove
2. Pump-side end plate
3. Driver
4. Pump half of the coupling guard

Check the rotation



WARNING:

- Operating the pump in reverse rotation can result in the contact of metal parts, heat generation, and breach of containment.
- Always disconnect and lock out power to the driver before you perform any installation or maintenance tasks. Failure to disconnect and lock out driver power will result in serious physical injury.

1. Lock out power to the driver.
2. Make sure that the coupling hubs are fastened securely to the shafts.
3. Make sure that the coupling spacer is removed.
The pump ships with the coupling spacer removed.
4. Unlock power to the driver.
5. Make sure that everyone is clear, and then jog the driver long enough to determine that the direction of rotation corresponds to the arrow on the bearing housing or close-coupled frame.
6. Lock out power to the driver.

Couple the pump and driver



WARNING:

Always disconnect and lock out power to the driver before you perform any installation or maintenance tasks. Failure to disconnect and lock out driver power will result in serious physical injury.

Couplings must have proper certification to be used in an ATEX classified environment. Use the instructions from the coupling manufacturer in order to lubricate and install the coupling.

Coupling guard assembly

Precautions




WARNING:

- Follow shaft alignment procedures in order to prevent catastrophic failure of drive components or unintended contact of rotating parts. Follow the coupling installation and operation procedures from the coupling manufacturer.
- Never operate the pump without the coupling guard correctly installed.
- Always disconnect and lock out power to the driver before you perform any installation or maintenance tasks. Failure to disconnect and lock out driver power will result in serious physical injury.
- The coupling used in an Ex-classified environment must be properly certified and must be constructed from a non-sparking material.

Required parts

These parts are required:




1. End plate, drive end
2. End plate, pump end
3. Guard half, 2 required
4. 3/8-16 nut, 3 required
5. 3/8 in. washer
6. 3/8-16 x 2 in. hex head bolt, 3 required

Install the coupling guard

1. Is the end plate (pump end) already installed?
 - If yes: Make any necessary coupling adjustments and then proceed to step 2.
 - If no: Complete these steps:
 - a) Remove the spacer portion of the coupling.

Refer to the instructions from the coupling manufacturer for assistance.

- b) If the coupling hub diameter is larger than the diameter of the opening in the end plate, then remove the coupling hub.
- c) Remove the three thrust bearing end cover and bearing frame screws.




234B	End plate
370N	Bearing frame bolts

- d) Align the end plate to the thrust bearing end cover so that the two slots in the end plate align with the bolts remaining in the end cover, and the three holes in the end plate align with the holes in the end cover.
- e) Replace the three thrust bearing end cover and bearing frame bolts and torque to the values shown in the Maximum torque values for 3700 fasteners table.
- f) Replace the coupling hub (if removed) and the spacer portion of the coupling.
Refer to the instructions from the coupling manufacturer for assistance.

Complete any coupling adjustments before you proceed with the coupling guard assembly.


2. Slightly spread the opening of the coupling guard half and place it over the pump end plate.



1. Pump half of the coupling guard
2. Annular groove
3. Deflector fan guard
4. Driver

The annular groove in the guard is located around the end plate.


Position the opening (flange) so that it does not interfere with the piping but still allows for access when you install the bolts.



1. Annular groove
2. Deflector fan guard
3. Coupling guard half


3. Place one washer over the bolt and insert the bolt through the round hole at the front end of the guard half.
4. Place a second washer over the exposed end of the bolt.
5. Thread a nut onto the exposed end of the bolt and tighten firmly.

This figure shows the proper sequence of components:




1. Nut
2. Washer
3. Bolt

This figure shows an assembled unit:




1. Driver
2. Coupling guard half

6. Slightly spread the opening of the remaining coupling guard half and place it over the installed coupling guard half so that the annular groove in the remaining coupling guard half faces the driver.




1. Annular groove
2. Coupling guard half
3. Driver

7. Place the end plate over the driver shaft and locate the end plate in the annular groove at the rear of the coupling guard half.



1. Annular groove
2. End plate


8. Repeat steps 3 through 5 for the rear end of the coupling guard half, except that you hand tighten the nut.
9. Slide the rear coupling guard half towards the motor so that it completely covers the shafts and coupling.



1. Driver
 2. Slide to fit
10. Repeat steps 3 through 5 for the center slots in the coupling guard.
 11. Firmly tighten all nuts on the guard assembly.

Install the coupling guard with the optional air cooling package

1. Is the deflector-fan guard support installed?
 - If yes: Make any necessary coupling adjustments and then proceed to step 2.
 - If no: Complete the following steps:
 - a) Remove the spacer portion of the coupling.
Refer to the coupling manufacturer's instructions.
 - b) If the coupling hub diameter is larger than the diameter of the opening in the deflector-fan guard support, then remove the coupling hub.
 - c) Loosen the thrust deflector-fan set screw.



122	Shaft
123B	Radial deflector fan
123E	Thrust deflector fan
222	Deflector set screw
228	Bearing frame
234	Thrust deflector-fan guard
234D	Thrust deflector-fan guard support
496Q	Support screws


- d) Slide the thrust deflector fan off of the shaft.
- e) Remove the thrust bearing end cover and the bearing frame screws.
- f) Align the thrust deflector-fan guard support with the thrust bearing end cover so that the support slots align with the holes in the end cover.
- g) Replace the thrust bearing end cover and bearing frame screws and torque to values shown in the Maximum torque values for 3700 fasteners table.




CAUTION:

Do not over-tighten the thrust bearing end cover and bearing frame screws.

- h) Install the thrust deflector fan over the shaft.
- i) Position the thrust deflector fan approximately 0.03 in. (0.8 mm) from the thrust bearing end cover and firmly tighten the deflector set screw.
- j) Slide the thrust deflector-fan guard over the guard support and align the holes in the guard with the tapped holes in the guard support.




2. Install the thrust deflector-fan guard and support screws and tighten to the torque values shown in the Maximum torque values for 3700 fasteners table.
3. Replace the coupling hub (if removed) and spacer portion of the coupling.
Refer to the coupling manufacturer's instructions for assistance.
Complete any coupling adjustments before you proceed with the coupling guard assembly.
4. Slightly spread the opening of the coupling-guard half and place it over the thrust deflector-fan guard so that the annular groove in the guard half is located around the guard support extension.




1. Rear coupling guard half
2. Annular groove
3. Deflector fan guard
4. Driver

Locate the opening (flange) so that it does not interfere with the piping but does allow access for installing the bolts.




1. Annular groove
 2. Deflector fan guard
 3. Coupling guard half
5. Place one washer over the bolt and insert the bolt through the round hole at the front end of the guard half.
 6. Place a second washer over the exposed end of the bolt and tighten it firmly.
 7. Thread a nut onto the exposed end of the bolt and tighten it firmly.

This figure shows the proper sequence of components:




1. Nut
2. Washer
3. Bolt

This figure shows an assembled unit:




1. Driver
 2. Coupling guard half
8. Slightly spread the opening of the remaining coupling guard half and place it over the installed coupling guard half so that the annular groove in the remaining coupling guard half faces the driver.




- 1. Annular groove
- 2. Coupling guard half
- 3. Driver

- 9. Place the end plate over the driver shaft and locate the end plate in the annular groove at the rear of the coupling guard half.



- 1. Annular groove
- 2. End plate

- 10. Repeat steps 5 through 7 for the rear end of the coupling guard half, except that you hand tighten the nut.
- 11. Slide the rear coupling guard half towards the motor so that it completely covers the shaft and coupling.



1. Driver
 2. Slide to fit
12. Repeat steps 5 through 7 for the center slots in the coupling guards.
 13. Firmly tighten all of the nuts on the guard assembly.

Bearing lubrication

Precautions



WARNING:

Make sure to properly lubricate the bearings. Failure to do so can result in excess heat generation, sparks, and premature failure.

Pumps are shipped without oil

You must lubricate oil-lubricated bearings at the job site.

Ring oil lubrication

Ring oil-lubricated bearings are standard. Bearing housings are supplied with constant-level oilers and sight glasses. Make sure that oil rings are properly seated in the grooves in the shaft.

Pure or purge oil-mist lubrication

Pure or purge oil-mist are optional features for the 3700. Follow the oil-mist generator manufacturer's instructions. The inlet and outlet connections are located on the top and bottom of the bearing frame, respectively.

Oil volumes

Oil volume requirements for ball/ball and sleeve/ball bearings

This table shows the required amount of oil for oil-lubricated bearings.

All frames in this table use a Watchdog Oiler, which has a capacity of 4 oz. (118 ml).

Frame	Frame oil volume	
	ounces	milliliters
SA	20	600
SX	38	1115
MA	32	950
MX, LA	47	1385
LX, XLA	72	2120

Frame	Frame oil volume	
	ounces	milliliters
XLX, XXL	89	2625

Lubricating-oil requirements

Oil quality requirements

Use a high-quality turbine oil with rust and oxidation inhibitors rated at 68 cSt. at 100°F (38°C).

Oil requirements based on temperature

For the majority of operating conditions, bearing temperatures run between 120°F (49°C) and 180°F (82°C), and you can use an oil of ISO viscosity grade 68 at 100°F (38°C). If temperatures exceed 180°F (82°C), refer to the table for temperature requirements.

Temperature	Oil requirement
Bearing temperatures exceed 180°F (82°C)	Use ISO viscosity grade 100. Bearing temperatures are generally about 20°F (11°C) higher than bearing-housing outer surface temperatures.
Pumped-fluid temperatures are extreme	Refer to the factory or a lubrication expert.

Acceptable oil for lubricating bearings

Acceptable lubricants

Brand	Lubricant type
Exxon	Teresstic EP 68
Mobil	DTE 768
Sunoco	Sunvis 968
Royal Purple	SYNFILM ISO VG 68 Synthetic Lube

Lubricate the bearings with oil


Ring oil-lubricated pumps are supplied with an oiler that maintains a constant oil level in the bearing housing.

1. Fill the oil reservoir in the bearing frame:
 - a) Fill the bearing chamber through the main body of the Watchdog until it reaches the optimum fluid level visible in the bullseye sight.
 - b) Fill the watchdog reservoir using a funnel.
 - c) Verify o-ring is on the Watchdog oiler spout.
 - d) Place your thumb over the reservoir spout. Invert and insert the spout into the internal threaded boss on the main body.
 - e) Tighten reservoir. Do not over-tighten.
 - f) Verify that proper oil level is maintained per the following diagram.

NOTICE:

Do not fill the oil reservoir of the bearing frame through the plug at the top.

2. Check that the oil level is correct. The correct oil level is centered in the bullseye sight glass, when the pump is not in operation. During operation, bullseye sight gives a false oil level reading.




1. Plug
2. Reservoir
3. Main body

Lubricate the bearings with pure or purge-oil mist (optional)

Before lubricating with purge-oil mist, make sure that the bearing frame is properly lubricated. See Lubricate the bearings with oil.

The oil requirements for ring-oil-lubricated bearings also apply to oil-mist-lubricated bearings.

1. Prepare the oil-mist generator according to the manufacturer's instructions.
2. Connect the oil-mist supply lines to the inlet connections.
3. Connect the drain and vent lines to the outlet connections.



1. Oil mist inlet
2. Oil mist outlet

Lubricate the bearings after a shutdown period

1. Flush out the bearings and bearing frame with a light oil to remove contaminants.
During flushing, make sure to rotate the shaft slowly by hand.
2. Flush the bearing housing with the proper lubricating oil to ensure oil quality after cleaning.

Shaft sealing with a mechanical seal

Precautions



WARNING:

The mechanical seal used in an Ex-classified environment must be properly certified. Prior to startup, make sure that all areas that could leak pumped fluid to the work environment are closed.

NOTICE:

- The mechanical seal must have an appropriate seal-flush system. Otherwise, excess heat generation and seal failure can occur.
- Cooling systems such as those for bearing lubrication and mechanical-seal systems must be operating properly to prevent excess heat generation, sparks, and premature failure.
- Sealing systems that are not self-purging or self-venting, such as plan 23, require manual venting prior to operation. Failure to do so will result in excess heat generation and seal failure.

Shipping

Pumps may be shipped with or without a mechanical seal installed.

Cartridge-type mechanical seals

Cartridge-type mechanical seals are commonly used. Cartridge seals are preset by the seal manufacturer and require no field settings. Cartridge seals installed by the user require disengagement of the holding clips prior to operation, allowing the seal to slide into place. If the seal has been installed in the pump by IIT, these clips have already been disengaged.

Other mechanical seal types

For other types of mechanical seals, refer to the instructions provided by the seal manufacturer for installation and setting.

Connection of sealing liquid for mechanical seals

Seal lubrication is required

Seal faces must have liquid film between them for proper lubrication. Locate the taps using the illustrations shipped with the seal.

Seal flushing methods


You can use these methods in order to flush or cool the seal:

Method	Description
Product flush	Run the piping so that the pump pushes the pumped fluid from the casing and injects it into the seal gland. If necessary, an external heat exchanger cools the pumped fluid before it enters the seal gland.
External flush	Run the piping so that the pump injects a clean, cool, compatible liquid directly into the seal gland. The pressure of the flushing liquid must be 5 to 15 psi (0.35 to 1.01 kg/cm ²) greater than the seal chamber pressure. The injection rate must be 0.5 to 2 gpm (2 to 8 lpm).
Other	You can use other methods that employ multiple gland or seal chamber connections. Refer to the mechanical seal reference drawing and piping diagrams.

Pump priming

Prime the pump with the suction supply above the pump

1. Slowly open the suction isolation valve.
2. Open the air vents on the suction and discharge piping until the pumped fluid flows out.
3. Close the air vents.



1. Discharge isolation valve
2. Check valve
3. Suction isolation valve


Prime the pump with the suction supply below the pump

Use a foot valve and an outside source of liquid in order to prime the pump. The liquid can come from one of these sources:

- A priming pump
- A pressurized discharge line
- Another outside supply


1. Close the discharge isolation valve.
2. Open the air vent valves in the casing.
3. Open the valve in the outside supply line until only liquid escapes from the vent valves.
4. Close the vent valves.
5. Close the outside supply line.

This illustration is an example of priming the pump with a foot valve and an outside supply:



1. Discharge isolation valve
2. Shutoff valve
3. From outside supply
4. Foot valve
5. Check valve

This illustration is an example of priming the pump with a foot valve using a bypass around the check valve:



1. By-pass line
2. Shutoff valve
3. Foot valve
4. Check valve
5. Discharge isolation valve

Other methods of priming the pump

You can also use these methods in order to prime the pump:

- Prime by ejector
- Prime by automatic priming pump

Start the pump



CAUTION:

- Immediately observe the pressure gauges. If discharge pressure is not quickly attained, stop the driver, reprime, and attempt to restart the pump.
- Observe the pump for vibration levels, bearing temperature, and excessive noise. If normal levels are exceeded, shut down the pump and resolve the issue.

Before you start the pump, you must perform these tasks:

- Open the suction valve.
 - Open any recirculation or cooling lines.
1. Fully close or partially open the discharge valve, depending on system conditions.
 2. Start the driver.
 3. Slowly open the discharge valve until the pump reaches the desired flow.
 4. Immediately check the pressure gauge to ensure that the pump quickly reaches the correct discharge pressure.
 5. If the pump fails to reach the correct pressure, perform these steps:
 - a) Stop the driver.
 - b) Prime the pump again.
 - c) Restart the driver.
 6. Monitor the pump while it is operating:
 - a) Check the pump for bearing temperature, excessive vibration, and noise.

- b) If the pump exceeds normal levels, then shut down the pump immediately and correct the problem.

A pump can exceed normal levels for several reasons. See Troubleshooting for information about possible solutions to this problem.

7. Repeat steps 5 and 6 until the pump runs properly.

Pump operation precautions

General considerations



CAUTION:

- Vary the capacity with the regulating valve in the discharge line. Never throttle the flow from the suction side since this can result in decreased performance, unexpected heat generation, and equipment damage.
- Do not overload the driver. Driver overload can result in unexpected heat generation and equipment damage. The driver can overload in these circumstances:
 - The specific gravity of the pumped fluid is greater than expected.
 - The pumped fluid exceeds the rated flow rate.
- Make sure to operate the pump at or near the rated conditions. Failure to do so can result in pump damage from cavitation or recirculation.

NOTICE: On ring oil-lubricated pumps, remove oil ring viewing port plugs to verify the following:

- The oil rings are properly positioned in the grooves on the shaft.
- The oil rings are turning.
- The oil rings are throwing oil.

Replace the plugs.

NOTICE:

- On pure or purge-oil mist-lubricated units, remove the viewing port plugs to verify that oil mist is flowing properly. Replace the plugs.
- On ring oil and purge-oil mist-lubricated pumps, make sure the oil level has remained steady by checking the oiler.
- Check the bearing temperatures using a pyrometer or other temperature-measuring device. Monitor the bearing temperature frequently during initial operation in order to determine if a bearing problem exists, as well as to establish normal bearing operating temperature.
- For pumps with auxiliary piping, make sure that proper flows have been established and that the equipment is operating properly.
- Establish baseline vibration readings in order to determine normal running conditions. If the unit is running roughly, then consult the factory.
- Monitor all gauges to ensure that the pump is running at or near rating and that the suction screen (when used) is not clogged.

Operation at reduced capacity



WARNING:

Never operate any pumping system with a blocked suction and discharge. Operation, even for a brief period under these conditions, can cause confined pumped fluid to overheat, which results in a violent explosion. You must take all necessary measures to avoid this condition.



CAUTION:

- Avoid excessive vibration levels. Excessive vibration levels can damage the bearings, stuffing box or seal chamber, and the mechanical seal, which can result in decreased performance.
 - Avoid increased radial load. Failure to do so can cause stress on the shaft and bearings.
 - Avoid heat build-up. Failure to do so can cause rotating parts to score or seize.
 - Avoid cavitation. Failure to do so can cause damage to the internal surfaces of the pump.
-

Operation under freezing conditions

NOTICE:

Do not expose an idle pump to freezing conditions. Drain all liquid that is inside the pump and the cooling coils. Failure to do so can cause liquid to freeze and damage the pump.

Shut down the pump



WARNING:

The pump can handle hazardous and toxic fluids. Identify the contents of the pump and observe proper decontamination procedures in order to eliminate the possible exposure to any hazardous or toxic fluids. Wear the proper personal protective equipment. Potential hazards include, but are not limited to, high temperature, flammable, acidic, caustic, explosive, and other risks. You must handle and dispose of pumped fluid in compliance with the applicable environmental regulations.

1. Slowly close the discharge valve.
 2. Shut down and lock the driver to prevent accidental rotation.
-

Make the final alignment of the pump and driver



WARNING:

- Always disconnect and lock out power to the driver before you perform any installation or maintenance tasks. Failure to disconnect and lock out driver power will result in serious physical injury.
 - Follow shaft alignment procedures in order to prevent catastrophic failure of drive components or unintended contact of rotating parts. Follow the coupling installation and operation procedures from the coupling manufacturer.
-

You must check the final alignment after the pump and driver are at operating temperature. For initial alignment instructions, see the Installation chapter.

1. Run the unit under actual operating conditions for enough time to bring the pump, driver, and associated system to operating temperature.
 2. Shut down the pump and the driver.
 3. Remove the coupling guard.
See Remove the coupling guard in the Maintenance chapter.
 4. Check the alignment while the unit is still hot.
See Pump-to-driver alignment in the Installation chapter.
 5. Reinstall the coupling guard.
 6. Restart the pump and driver.
-

Dowel the pump casing (optional)

You will need the following tools:

- Two number 7 taper pins
- One number 7 taper pin reamer
- 0.3320 in. or "Q" size drill
- Hardwood block or soft-faced hammer

Also make sure that the final alignment is complete.

Dowel the pump casing to the baseplate pedestals in order to make sure that you maintain the proper pump position.

1. Drill two holes, one in each casing mounting pad, at the locations provided.

Drill the holes through both the casing mounting pads and the baseplate pedestal, when possible. This makes it easier to clean the metal chips produced from the drilling and reaming operations.

NOTICE: If water-cooled pedestals have been provided, then do not drill through the baseplate pedestal. Doing so can result in leakage of cooling water.

2. Clean all burrs and metal chips from the holes.
 3. Ream the holes with a number 7 taper pin reamer to the proper fit with the taper dowel pins. Insert the pins deep enough that only the threaded portion is exposed when the pin is fully seated.
 4. Seat the taper pins firmly in the holes with a hardwood block or soft-faced hammer.
-

NOTICE: Always remove the dowel pins before removing the casing. Failure to do so can result in casing damage.

Maintenance

Maintenance schedule

Maintenance inspections

A maintenance schedule includes these types of inspections:

- Routine maintenance
- Routine inspections
- Three-month inspections
- Annual inspections

Shorten the inspection intervals appropriately if the pumped fluid is abrasive or corrosive or if the environment is classified as potentially explosive.

Routine maintenance

Perform these tasks whenever you perform routine maintenance:

- Lubricate the bearings.
- Inspect the seal.

Routine inspections

Perform these tasks whenever you check the pump during routine inspections:

- Check the level and condition of the oil through the sight glass on the bearing frame.
- Check for unusual noise, vibration, and bearing temperatures.
- Check the pump and piping for leaks.
- Analyze the vibration.
- Inspect the discharge pressure.
- Inspect the temperature.
- Check the seal chamber and stuffing box for leaks.
 - Ensure that there are no leaks from the mechanical seal.
 - Adjust or replace the packing in the stuffing box if you notice excessive leaking.

Three-month inspections

Perform these tasks every three months:

- Check that the foundation and the hold-down bolts are tight.
- Check the mechanical seal if the pump has been left idle, and replace as required.
- Change the oil every three months (2000 operating hours) at minimum.
 - Change the oil more often if there are adverse atmospheric or other conditions that might contaminate or break down the oil.
- Check the shaft alignment, and realign as required.

Annual inspections

Perform these inspections one time each year:

- Check the pump capacity.
- Check the pump pressure.
- Check the pump power.
- Inspect all plugs and seals in the power end.

If the pump performance does not satisfy your process requirements, and the process requirements have not changed, then perform these steps:

1. Disassemble the pump.
2. Inspect it.
3. Replace worn parts.

Bearing maintenance

These bearing lubrication sections list different temperatures of the pumped fluid. If the pump is ATEX-certified and the temperature of the pumped fluid exceeds the permitted temperature values, then consult your ITT representative.

Bearing lubrication schedule

Type of bearing	First lubrication	Lubrication intervals
Oil-lubricated bearings	Add oil before you install and start the pump. Change the oil after 200 hours for new bearings.	After the first 200 hours, change the oil every 2000 operating hours or every three months.

Mechanical-seal maintenance



WARNING:

The mechanical seal used in an Ex-classified environment must be properly certified. Prior to startup, make sure that all areas that could leak pumped fluid to the work environment are closed.



CAUTION:

Never operate the pump without liquid supplied to mechanical seal. If you run a mechanical seal dry, even for a few seconds, this can cause seal damage. Physical injury can occur if a mechanical seal fails.

NOTICE:

- Sealing systems that are not self-purging or self-venting, such as plan 23, require manual venting prior to operation. Failure to do so will result in excess heat generation and seal failure.
- Cooling systems, such as those for bearing lubrication and mechanical-seal systems, must be operating properly to prevent excess heat generation, sparks, and premature failure.
- The mechanical seal must have an appropriate seal flush system or excess heat generation and seal failure can occur.

Before you start the pump

Check the seal and all flush piping.

Mechanical seal life

The life of a mechanical seal depends on the cleanliness of the pumped fluid. Due to the diversity of operating conditions, it is not possible to give definite indications as to the life of a mechanical seal.

Disassembly

Disassembly precautions



WARNING:

- This manual clearly identifies accepted methods for disassembling units. These methods must be adhered to. Trapped liquid can rapidly expand and result in a violent explosion and injury. Never apply heat to impellers, propellers, or their retaining devices to aid in their removal.
 -
 - Always disconnect and lock out power to the driver before you perform any installation or maintenance tasks. Failure to disconnect and lock out driver power will result in serious physical injury.
 - Crush hazard. The unit and the components can be heavy. Use proper lifting methods and wear steel-toed shoes at all times.
 - The pump can handle hazardous and toxic fluids. Identify the contents of the pump and observe proper decontamination procedures in order to eliminate the possible exposure to any hazardous or toxic fluids. Wear the proper personal protective equipment. Potential hazards include, but are not limited to, high temperature, flammable, acidic, caustic, explosive, and other risks. You must handle and dispose of pumped fluid in compliance with the applicable environmental regulations.
 - A worn pump can have components that have very sharp edges. Wear protective gloves.
-

NOTICE:

Make sure that all replacement parts are available before you disassemble the pump for overhaul.

Tools required

In order to disassemble the pump, you need these tools:

- Allen wrenches
- Brass drift punch
- Cleaning agents and solvents
- Dial indicators
- Drill
- Feeler gauges
- Induction heater
- Lifting sling
- Micrometer
- Open end wrenches
- Press
- Soft face hammer
- Spanner wrench
- Spanning type puller
- Tap
- Torque wrench with sockets

Drain the pump

**CAUTION:**

- Allow all system and pump components to cool before you handle them to prevent physical injury.
- If your pump is a Model NM3171, NM3196, 3198, 3298, V3298, SP3298, 4150, 4550, or 3107 there is a possible risk of static electric discharge from plastic parts that are not properly grounded. If the pumped fluid is non-conductive, drain and flush the pump with a conductive fluid under conditions that will not allow for a spark to be released to the atmosphere.

-
1. Close the isolation valves on the suction and discharge sides of the pump.
You must drain the system if no valves are installed.
 2. Open the drain valve.
Do not proceed until liquid stops coming out of the drain valve. If liquid continues to flow from the drain valve, the isolation valves are not sealing properly and you must repair them before you proceed.
 3. Leave the drain valve open and remove the drain plug located on the bottom of the pump housing.
Do not reinstall the plug or close the drain valve until the reassembly is complete.
 4. Drain the liquid from the piping and flush the pump if it is necessary.
 5. Disconnect all auxiliary piping and tubing.
 6. Remove the oiler bottle and store it in a safe place.
 7. Remove the coupling guard.
 8. Remove the coupling spacer.
Follow the coupling manufacturer's instructions for assistance.
 9. Disconnect the coupling.

Remove the back pull-out assembly


**CAUTION:**

Never remove the back pull-out assembly without assistance.

-
1. Remove the casing stud nuts.


**WARNING:**

- If you must use heat to remove parts, you must drain all liquid and remove all vapor. To do this, purge the casing, seal chamber, and so forth, with dry compressed air or inert gas.
-
2. Tighten the jackscrews evenly, using an alternating pattern, in order to remove the back pull-out assembly.
You can use penetrating oil if the adapter to the casing joint is corroded.



184	Seal chamber cover
418	Jackscrew

- Remove the back pull-out assembly using a lifting sling through the bearing frame.



- Remove and discard the casing gasket.
You will insert a new casing gasket during reassembly.
- Remove the jackscrews.
- Clean all gasket surfaces.
Clean surfaces prevent the casing gasket from partially adhering to the casing due to binders and adhesives in the gasket material.
- Secure the back pull-out assembly to prevent movement during transport.
- Transport the back pull-out assembly to a clean work area for further disassembly.

Remove the coupling hub

- If the coupling hub overhangs the shaft, mark the shaft for relocating the coupling hub during reassembly.
Coupling hubs are normally mounted flush with the end of the shaft.
- Remove the coupling hub using a spanning-type puller or puller holes provided in the hub.
Refer to the coupling manufacturer's instructions for assistance.


Remove the impeller



CAUTION:

Wear heavy work gloves when you handle impellers. The sharp edges can cause physical injury.

- Loosen the set screw at the end of the impeller nut.
- Loosen and remove the impeller nut.
The impeller nut has left-hand threads.




122	Shaft
198A	Set screw
304	Impeller nut


3. Pull the impeller from the shaft.
Use a spanning-type puller if required.
4. Remove the impeller key.
Save the key for reassembly unless it is damaged.

Remove the seal-chamber cover

1. Loosen and remove the gland stud nuts.
2. Slide the cartridge mechanical seal away from the seal-chamber cover.



3. Install the eyebolt in the tapped hole provided in the seal-chamber cover.
4. Rig the lifting sling to the eyebolt and the overhead lifting device.
5. Loosen and remove the seal-chamber cover and the bearing frame bolts.
6. Separate the seal-chamber cover from the bearing frame by tapping on the cover flange with a hardwood block or a soft-face hammer.



122	Shaft
184	Seal-chamber cover
228	Bearing frame
355	Gland stud nuts
360Q	Gland gasket
370H	Bearing frame bolts

7. Guide the seal-chamber cover over the end of the shaft once the cover releases from the bearing frame.

NOTICE: The cartridge mechanical seal may become damaged if the cover is allowed to come in contact with it.

8. Loosen the setscrews and remove the cartridge mechanical seal from the shaft.
9. Remove and discard the mechanical seal O-ring or gland gasket.
You will replace this with a new O-ring or gasket during reassembly.

Remove the optional water-jacket cover



CAUTION:

- The seal-chamber cover must be adequately supported so that it cannot fall.
- You must vent all air from the water jacket. If all of the air is not vented, it can cause the water jacket cover to be propelled from its fit in the seal-chamber cover.
- Do not exceed 7.0 kg/cm² (100 psig) pressure in the water jacket.

1. Suspend the seal-chamber cover from the lifting sling, or firmly support the seal-chamber cover in a vertical position such that one water-jacket connection is on the top and the other is on the bottom.
2. Slowly replace all the air with water until all air is vented and only water comes out of the top connection.
3. Seal the top connection with a plug or other suitable means.
4. Slowly increase water pressure on the inlet (bottom) connection to force the water-jacket cover from its fit in the seal-chamber cover.
Be prepared to catch the water-jacket cover.
5. Remove and discard the outer and inner water-jacket cover O-rings from the grooves in the water-jacket cover.
You will replace these with new O-rings during reassembly.

Disassemble the power end

This procedure explains how to disassemble a standard ring-oil or optional purge-oil mist-lubricated power end and includes information for the disassembly of these optional features:

- Pure oil-mist-lubricated power end
- Radial-heat-flinger end
- Air-cooling package
- Water-cooling package




CAUTION:

Do not remove bearings from the shaft unless you need to replace them.

The optional pure-oil mist-lubricated power ends are disassembled in the same manner as ring oil-lubricated power ends. Oil rings are not furnished with pure-oil-mist lubrication. Disregard any references to those parts.


1. Does your power end have an optional air-cooling package?
 - If no: Go to step 2.
 - If yes:
 - a) Loosen the radial-heat-flinger set screw.
 - b) Loosen the thrust-fan set screw.

The thrust fan for the SA and MA pumps sits on the coupling diameter.
 - c) Slide the thrust fan off the shaft.
 - d) Loosen and remove the thrust-bearing end cover and bearing-frame screws.
 - e) Remove the thrust-fan guard support.




122	Shaft
123B	Radial deflector fan
123E	Thrust deflector fan
222	Deflector set screw
228	Bearing frame
234	Thrust deflector-fan guard
234D	Thrust deflector-fan guard support
496Q	Support screws

2. Loosen and remove the thrust-bearing end cover and bearing-frame screws.
3. Pry the thrust-bearing end cover thrust deflector out of the bearing frame.
SA and MA thrust-bearing end covers are sealed to the bearing frame with a gasket.



109A	Thrust-bearing end cover
122	Shaft
123A	Thrust deflector
228	Bearing frame
358E	Oil ring inspection plug
360A	Gasket
370N	Bearing-frame screw
390C	Thrust-bearing end-cover shim
469P	Oil ring retainer




4. Remove and discard the thrust-bearing end-cover shims.
For all except SA and MA bearing frames, replace with new shims during reassembly.
5. Remove the two oil ring retainers and the oil ring inspection plugs from the top of the bearing frame.

SX, MX, LA, LX, XLA, and XLX pumps have two inspection plugs. SA and MA pumps have one inspection plug.

6. If your power end has the optional water-cooling package, then remove the finned-tube cooling assembly from the bearing frame.
7. Carefully withdraw the shaft and bearing assembly from the bearing frame.

Take care not to damage the oil rings. If the oil rings bind or hang up, you can access them through the inspection holes and reposition them using a hooked tool made from wire. SX, MX, LA, LX, XLA, and XLX pumps have two oil rings. SA and MA pumps have one oil ring.



112	Duplex thrust bearing
114	Oil rings
122	Shaft
136	Thrust-bearing locknut
168	Radial bearing
382	Lockwasher

8. Bend the locking tang of the thrust-bearing lockwasher away from the notch in the bearing locknut.

NOTICE:

Save the bearings for inspection. Do not reuse the bearings. Doing so may result in decreased performance.

9. Remove the radial bearing from the shaft:
 - a) Loosen and remove the thrust-bearing locknut and lockwasher.
 - b) Press or pull the duplex thrust bearing from the shaft.
 - c) Remove the oil ring(s) from the shaft.

SX, MX, LA, LX, XLA, and XLX pumps have two oil rings. SA and MA pumps have one oil ring.
 - d) Press or pull the radial bearing from the shaft.
10. Perform the following based on your pump version:

If your pump is...	Then...										
SX, MX, LA, LX, XLA, or XLX	<ol style="list-style-type: none"> 1. Loosen and remove the radial-bearing end cover and bearing-frame screws. 2. Remove and discard the radial-bearing end-cover gasket. You will replace this with a new gasket during reassembly. 3. Press the radial and thrust deflector out of the radial and thrust end covers. <p>If you have an optional radial heat flinger, it replaces the standard radial deflector and is removed in the same manner except you loosen three set screws.</p> <div data-bbox="667 464 1166 821" style="text-align: center;"> </div> <table border="1" data-bbox="646 963 1474 1192" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">119A</td> <td>Thrust end cover</td> </tr> <tr> <td>123</td> <td>Deflector</td> </tr> <tr> <td>228</td> <td>Bearing frame</td> </tr> <tr> <td>360</td> <td>Radial-bearing end-cover gasket</td> </tr> <tr> <td>370P</td> <td>Bearing-frame screws</td> </tr> </table>	119A	Thrust end cover	123	Deflector	228	Bearing frame	360	Radial-bearing end-cover gasket	370P	Bearing-frame screws
119A	Thrust end cover										
123	Deflector										
228	Bearing frame										
360	Radial-bearing end-cover gasket										
370P	Bearing-frame screws										
SA and MA	<p>Remove the radial-bearing end cover and radial deflector with gasket or radial deflector from the bearing frame by tapping it out of the frame.</p> <p>If you have an optional radial heat flinger, it replaces the standard radial deflector and is removed in the same manner except you loosen three set screws.</p> <div data-bbox="667 1373 1230 1717" style="text-align: center;"> </div>										

11. Remove any remaining plugs and fittings.

Preassembly inspections

Replacement guidelines

Casing check and replacement


Inspect the casing for cracks and excessive wear or pitting. Thoroughly clean gasket surfaces and alignment fits in order to remove rust and debris.

Repair or replace the casing if you notice any of these conditions:

- Localized wear or grooving that is greater than 1/8 in. (3.2 mm) deep
- Pitting that is greater than 1/8 in. (3.2 mm) deep
- Irregularities in the casing-gasket seat surface

Casing areas to inspect

The arrows point to the areas to inspect for wear on the casing:



100	Casing
164	Casing wear ring

Figure 9: 3700 casing

Impeller replacement

This table shows the criteria for replacing the impeller:

Impeller parts	When to replace
Impeller vanes	<ul style="list-style-type: none"> • When grooved deeper than 1/16 in. (1.6 mm), or • When worn evenly more than 1/32 in. (0.8 mm)
Pumpout vanes	When worn or bent more than 1/32 in. (0.8 mm)
Vane edges	When you see cracks, pitting, or corrosion damage


Impeller checks

- Check and clean the impeller bore diameter.
- Check the impeller balance. Rebalance the impeller if it exceeds the ISO 1940 G1.0 criteria.

NOTICE:

You must have extremely accurate tooling equipment to balance impellers to the ISO 1940 G1.0 criteria. Do not attempt to balance impellers to this criteria unless this type of tooling and equipment is available.

Impeller areas to inspect



101	Impeller
202 and 203	Impeller wear rings

Figure 10: Areas to inspect for wear on the 3700 pump

Oil ring replacement

Oil rings must be as round as possible in order to function properly. Replace oil rings if they are worn, distorted, or damaged beyond reasonable repair.

Cartridge mechanical seal replacement

Cartridge-type mechanical seals should be serviced by the seal manufacturer. Refer to the instructions from the mechanical seal manufacturer for assistance.

Coupling guard replacement

Repair or replace the coupling guard if you notice corrosion or other defects.

Gaskets, O-rings, and seats replacement

- Replace all gaskets and O-rings at each overhaul and disassembly.
- Inspect the seats. They must be smooth and free of physical defects.

In order to repair worn seats, skin cut them in a lathe while you maintain dimensional relationships with other surfaces.

- Replace parts if the seats are defective.

Additional parts

Inspect and either repair or replace all other parts, if inspection indicates continued use would be harmful to satisfactory and safe pump operation.

Inspection must include the following items:

- Bearing end covers (109A) and (119A)
- INPRO radial deflector (123) and thrust deflector (123A)

- Radial heat flinger (123B)*
- Thrust fan (123E)*
- Bearing locknut (136)
- Impeller key (178) and coupling key
- Impeller screw (198)
- Impeller washer (199)
- Impeller lockwasher (199A)
- Impeller nut (304)
- Bearing lockwasher (382)
- Water jacket cover (490)*
- All nuts, bolts, and screws

* If supplied.

Shaft replacement guidelines

Shaft measurement check

Check the bearing fits of the shaft. If any are outside the tolerances shown in the Bearing fits and tolerances table, then replace the shaft.

Shaft straightness check


Check the shaft straightness. Use “V” blocks or balance rollers to support the shaft on the bearing fit areas. Replace the shaft if runout exceeds 0.001 in. (0.03 mm).

NOTICE:

Do not use shaft centers for the runout check as they may have been damaged during the removal of the bearings or impeller.

Shaft surface check

Check the shaft surface for damage, especially in areas indicated by the arrows in the following figure. Replace the shaft if it is damaged beyond reasonable repair.



Bearings inspection

Condition of bearings

Do not reuse bearings. The condition of the bearings provides useful information on operating conditions in the bearing frame.

Checklist

Perform these checks when you inspect the bearings:

- Inspect the bearings for contamination and damage.
- Note any lubricant condition and residue.
- Inspect the ball bearings to see if they are loose, rough, or noisy when you rotate them.
- Investigate any bearing damage to determine the cause. If the cause is not normal wear, correct the issue before you return the pump to service.

Replacement bearings

Replacement bearings must be the same as, or equivalent to, those listed in this table.

Table 4: 3700 bearings based on SKF / MRC designations

Group	Radial (inboard)	Thrust (outboard)
SA	6210 C3	7310 BEGAM
MA	6211 C3	7311 BEGAM
SX	6212 C3	7312 BEGAM
MX, LA	6213 C3	7312 BEGAM
LX, XLA	6215 C3	7313 BEGAM
XLX	6218 C3	7317 BEGAM
XXL	6220 C3	7318 BEGAM


Wear rings inspection and replacement

Wear ring types

All units are equipped with casing, impeller, and seal-chamber cover wear rings. When clearances between the rings become excessive, hydraulic performance decreases substantially.


Wear ring diameter check

Measure all wear ring diameters and then calculate the diametrical wear ring clearances. See the Minimum running clearances table for more information.




100	Casing
164	Casing wear ring

Figure 11: Casing wear ring



101	Impeller
202	Impeller wear ring
203	Impeller wear ring

Figure 12: Impeller wear ring



125	Seal-chamber throat bushing
184	Seal-chamber cover
230	Seal-chamber cover wear ring

Figure 13: Seal chamber cover wear ring

When to replace wear rings

Replace wear rings when the diametrical clearance exceeds two times the minimum clearance as shown in this table or when the hydraulic performance has decreased to unacceptable levels.

Table 5: Minimum running clearances

Diameter of impeller wear ring		Minimum diametrical clearance	
in.	mm	in.	mm
<2.000	<50	0.010	0.25
2.000 to 2.4999	50 to 64.99	0.011	0.28
2.500 to 2.999	65 to 79.99	0.012	0.30
3.000 to 3.499	80 to 89.99	0.013	0.33
3.500 to 3.999	90 to 99.99	0.014	0.35
4.000 to 4.499	100 to 114.99	0.015	0.38
4.500 to 4.999	115 to 124.99	0.016	0.40
5.000 to 5.999	125 to 149.99	0.017	0.43
6.000 to 6.999	150 to 174.99	0.018	0.45
7.000 to 7.999	175 to 199.99	0.019	0.48
8.000 to 8.999	200 to 224.99	0.020	0.50
9.000 to 9.999	225 to 249.99	0.021	0.53
10.000 to 10.999	250 to 274.99	0.022	0.55
10.000 to 11.999	275 to 299.99	0.023	0.58
12.000 to 12.999	300 to 324.99	0.024	0.60

Replace the wear rings



WARNING:

Dry ice and other chilling substances can cause physical injury. Contact the supplier for information and advice for proper handling precautions and procedures.



CAUTION:


- Excessive machining can damage ring fits and render parts unusable.
- Wear insulated gloves when you handle rings. Rings will be hot and can cause physical injury.
- For runout checks, firmly support the bearing-frame assembly in the horizontal position.
- Wear heavy work gloves when you handle impellers. The sharp edges can cause physical injury.

NOTICE:

The impeller and wear-ring clearance setting procedures must be followed. Improperly setting the clearance or not following any of the proper procedures can result in sparks, unexpected heat generation, and equipment damage.

Casing, impeller, and seal chamber cover wear rings are held in place by a press fit and three set screws.


1. Remove the wear rings:
 - a) Remove the set screws.
 - b) Remove the wear rings from the casing, impeller, and seal-chamber cover using a pry or puller to force the rings from the fits.
2. Clean the wear-ring seats thoroughly, and make sure that they are smooth and free of scratches.
3. Heat the new impeller wear rings to 180° to 200°F (82° to 93°C) using a uniform method for heating, such as an oven, and place them on the impeller wear-ring seats.



101	Impeller
202	Impeller wear ring
203	Impeller wear ring
320	Set screw


4. Chill the new casing wear ring using dry ice or another suitable chilling substance and install the ring into the casing fit.

Be prepared to tap the ring in place with a wood block or soft-faced hammer.




100	Casing
164	Casing wear ring
222E	Set screw

5. Insert a new seal-chamber-cover wear ring:
 - a) Chill a new seal-chamber-cover wear ring, using dry ice or another suitable chilling substance, and install the ring into the cover fit.
Be prepared to tap the ring in place with a hardwood block or soft faced hammer.
 - b) Locate, drill, and tap three new equally-spaced set screw holes between the original holes in each new ring and ring-seat area.
 - c) Install the set screws and upset threads.



184	Cover
222E	Set screw
230	Seal-chamber-cover wear ring

6. Check the casing wear ring runout and distortion:
 - a) Measure the bore at each set screw location with inside micrometers or vernier calipers.
 - b) Correct any distortion in excess of 0.003 in. (0.08 mm) by machining before you trim the new impeller wear rings.




100	Casing
164	Casing wear ring


7. Measure the bore of the casing wear ring to establish the required impeller wear-ring diameter you use to provide the recommended running clearances.
8. Repeat steps 6 and 7 for the seal-chamber wear ring.
9. Turn the impeller wear rings to size after you mount them on the impeller:

NOTICE:

- All replacement impeller wear rings, except those that are hard-faced, are supplied 0.020 in. to 0.030 in. (0.51 mm to 0.75 mm) oversize.
- Do not machine all wear rings. Spare hard-faced impeller wear rings are supplied to pre-established clearances when both impeller and casing wear rings are renewed.



10. Install the impeller:
 - a) Install the impeller key on the shaft of the assembled bearing frame from which the seal-chamber cover has been removed, and on which the runouts are within the established specifications. The key should be at the top (12 o'clock) position for the impeller installation.
 - b) Install the impeller on the shaft.
 - c) Install the impeller washer.
 - d) Secure the impeller firmly with an impeller screw or impeller nut.
The impeller screw has left-hand threads.
11. Check the impeller wear-ring runout:
 - a) Mount the dial indicator.
 - b) Rotate the shaft so that the indicator rides along the casing-side impeller wear-ring surface for 360°.
 - c) Repeat steps a and b for the wear ring on the seal-chamber cover side.



101	Impeller
122	Shaft
202	Casing-side impeller wear-ring
228	Seal-chamber cover side wear ring

If the impeller wear ring runout is in excess of 0.005 in. (0.13 mm):

1. Check for distortion at the set screw areas.
2. Check the shaft runout and all mating surfaces of the shaft and impeller hub for perpendicularity.
3. True up all damaged surfaces.
4. Recheck the impeller wear-ring runout.

Seal-chamber cover inspection and replacement

Two seal-chamber cover versions


The seal-chamber cover is available in two versions:

- Standard
- Optional

The optional version has a cooling chamber and water jacket cover and is used when elevated pumped-fluid temperatures are present.

Seal-chamber cover areas to inspect

- Ensure all gasket/O-ring sealing surfaces are clean and have no damage that would prevent sealing.
- Ensure that all cooling (where applicable), flush, and drain passages are clear.



125	Seal-chamber throat bushing
184	Seal-chamber cover
230	Seal-chamber cover wear ring


Seal-chamber cover replacement

Seal-chamber cover part	When to replace
Seal-chamber cover surfaces	When worn, damaged, or corroded more than 0.126 in. (3.2 mm) deep
Inside diameter of seal-chamber cover bushing	When the diametral clearance between the bushing and the impeller hub exceeds 0.047 in. (1.20 mm)

Replace the seal-chamber cover bushing

The seal-chamber cover bushing is held in place by a press fit and locked by three set screws.

1. Remove the bushing:
 - a) Remove the set screws.
 - b) Press the bushing out of the fit towards the bearing-frame side of the seal-chamber cover bore.



125	Bushing
184	Seal-chamber cover


2. Install the new seal-chamber cover bushing:
 - a) Thoroughly clean the bushing fit in the seal-chamber cover.
 - b) Chill the new bushing using dry ice or another suitable chilling substance, and install the bushing into the cover fit.
Tap the bushing in place with a wood block or soft-faced hammer.



WARNING:

Dry ice and other chilling substances can cause physical injury. Contact the supplier for information and advice for proper handling precautions and procedures.

- c) Locate, drill, and tap three new equally-spaced set screw holes on the impeller side of the cover between the original set screw holes.
- d) Install the set screws and upset threads.



1. Seal-chamber cover
2. Set screws
3. Bushing

Bearing-frame inspection

Checklist

Check the bearing frame for these conditions:

- Visually inspect the bearing frame and frame foot for cracks.
- Check the inside surfaces of the frame for rust, scale, or debris. Remove all loose and foreign material.
- Make sure that all lubrication passages are clear.
- Inspect the inboard-bearing bores.

If any bores are outside the measurements in the Bearing fits and tolerances table, replace the bearing frame.

Surface inspection locations

This figure shows the areas to inspect for wear on the bearing frame surface.




Figure 14: Surface inspection locations

Bearing fits and tolerances

This table references the bearing fits and tolerances according to ISO 286 (ANSI/ABMA Standard 7) in inches (millimeters).

Table 6: Bearing fits and tolerances table (SI units)

Location	Description	SA	SX	MA	MX, LA	LX, XLA	XLX	XXL	
Radial (Inboard)	Shaft OD	1.9690 (50.013)	2.3628 (60.015)	2.1659 (55.015)	2.5597 (65.015)	2.9534 (75.015)	3.5440 (90.018)	3.9377 (100.018)	
		1.9686 (50.002)	2.3623 (60.002)	2.1654 (55.002)	2.5592 (65.002)	2.9529 (75.002)	3.5434 (90.003)	3.9371 (100.002)	
	Interference	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.003)	0.0001 (0.002)
		0.0010 (0.025)	0.0012 (0.030)	0.0012 (0.030)	0.0012 (0.030)	0.0012 (0.030)	0.0012 (0.030)	0.0015 (0.038)	0.001 (0.038)
	Bearing ID	1.9680 (49.988)	2.3616 (59.985)	2.1647 (54.985)	2.5585 (64.985)	2.9522 (74.985)	3.5425 (89.980)	3.9362 (99.980)	
		1.9685 (50.000)	2.3622 (60.000)	2.1653 (55.000)	2.5591 (65.000)	2.9528 (75.000)	3.5433 (90.000)	3.9370 (100.000)	
	Frame ID	3.5433 (90.000)	4.3307 (110.000)	3.9370 (100.000)	4.7244 (120.000)	5.1181 (130.000)	6.2992 (160.000)	7.0866 (180.000)	
		3.5442 (90.022)	4.3316 (110.022)	3.9378 (100.022)	4.7253 (120.022)	5.1191 (130.025)	6.3002 (160.025)	7.0875 (180.023)	
	Clearance	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)
		0.0015 (0.037)	0.0015 (0.037)	0.0015 (0.037)	1.0015 (0.037)	0.0017 (0.043)	0.0020 (0.050)	0.0012 (0.048)	
	Bearing OD	3.5483 (90.000)	4.3307 (110.000)	3.9390 (100.000)	4.7244 (120.000)	5.1181 (130.000)	6.2992 (160.000)	7.0866 (180.000)	
		3.5427 (89.985)	4.3301 (110.022)	3.9363 (99.985)	4.7238 (119.985)	5.1174 (129.982)	6.2982 (159.975)	7.0856 (179.975)	
Thrust (Outboard)	Shaft OD	1.9691 (50.013)	2.3628 (60.015)	2.1659 (55.015)	2.3628 (60.015)	2.5597 (65.015)	3.3472 (85.018)	3.544 (90.018)	
		1.9686 (50.002)	2.3623 (60.002)	2.1654 (55.002)	2.3623 (60.002)	2.5592 (65.002)	3.3466 (85.003)	3.5434 (90.002)	
	Interference	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.002)	0.0001 (0.003)	0.0001 (0.002)
		0.0010 (0.025)	0.0012 (0.030)	0.0012 (0.025)	0.0012 (0.030)	0.0012 (0.030)	0.0012 (0.030)	0.0015 (0.038)	0.002 (0.038)
	Bearing ID	1.9680 (49.998)	2.3616 (59.985)	2.1647 (54.985)	2.3616 (59.985)	2.5585 (64.985)	3.3457 (84.980)	3.5425 (89.980)	
		1.9685 (50.000)	2.3622 (60.000)	2.1653 (55.000)	2.3622 (60.000)	2.5591 (65.000)	3.3465 (85.000)	3.5433 (90.000)	
	Frame ID	4.3307 (110.000)	5.1181 (130.000)	4.7244 (120.000)	5.1181 (130.000)	5.5118 (140.000)	7.0866 (180.000)	7.4802 (190.000)	
		4.3315 (110.022)	5.1191 (130.025)	4.7253 (120.022)	5.1191 (130.025)	5.5128 (140.025)	7.0876 (180.025)	7.4814 (190.028)	
	Clearance	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)	0.0000 (0.000)
		0.0015 (0.037)	0.0017 (0.043)	0.0015 (0.037)	0.0017 (0.043)	0.0017 (0.043)	0.0020 (0.050)	0.0002 (0.0053)	
	Bearing OD	4.3307 (110.000)	5.1181 (130.000)	4.7244 (120.000)	5.1181 (130.000)	5.5118 (140.000)	7.0866 (180.000)	7.4802 (190.000)	
		4.3301 (109.985)	5.1174 (129.982)	4.7238 (119.985)	5.1174 (129.982)	5.5111 (139.982)	7.0856 (179.975)	7.4793 (189.975)	

Reassembly

Assemble the power end

This procedure explains how to assemble a standard ring-oil or optional purge-oil mist-lubricated power end and includes information for the assembly of these optional features:

- Pure-oil mist-lubricated power end
- Radial-heat-flinger
- Air-cooling package
- Water-cooling package

**WARNING:**

Crush hazard. The unit and the components can be heavy. Use proper lifting methods and wear steel-toed shoes at all times.

**CAUTION:**


- Wear insulated gloves when you use a bearing heater. Bearings get hot and can cause physical injury.
 - This pump uses duplex bearings mounted back-to-back. Make sure orientation of the bearings is correct.
-

NOTICE:

- There are several methods you can use to install bearings. The recommended method is to use an induction heater that heats and demagnetizes the bearings.
 - Make sure that all parts and threads are clean and that you have followed all directions under the Preassembly inspections section.
 - Check for magnetism on the pump shaft and degauss the shaft if there is any detectable magnetism. Magnetism attracts ferritic objects to the impeller, seal, and bearings which can result in excessive heat generation, sparks, and premature failure.
-

Pure oil-mist lubricated power ends are assembled in the same manner as ring oil-lubricated power ends. Oil rings are not furnished with pure oil-mist lubrication. Disregard any reference to those parts.

1. Install the radial (inboard) bearing on the shaft.




112	Duplex thrust bearing
114	Oil rings
122	Shaft
136	Thrust-bearing locknut
168	Radial bearing
382	Lockwasher

2. Install the oil rings and bearings:
 - a) Install the oil rings on the shaft.

Pump type	Oil rings
SX, MX, LA, LX, XLA, and XLX	2
SA and MA	1


- b) Install the thrust (outboard) bearings on the shaft.
 - c) Place the bearing lockwasher on the shaft and the tang of the lockwasher in the keyway.
 - d) Thread the bearing locknut onto the shaft.
 After the bearings and the shaft have cooled to the ambient temperature, tighten the locknut to the torque values shown in the Maximum torque values for 3700 fasteners table.
 - e) Bend a tang of the bearing lockwasher into a slot of the locknut.
 - f) Coat the internal bearing surfaces with lubricant to be used in service.



119A	Thrust end cover
123	Deflector
228	Bearing frame
360	Radial-bearing end-cover gasket
370P	Bearing-frame screws


3. Press the radial INPRO oil seal into the radial end cover.
4. Install the radial-bearing end cover and new end-cover gasket on the bearing frame. Make sure that the expulsion part is at the 6 o'clock position and is properly seated. For the optional air-cooling package, the radial-heat flinger replaces the standard radial INPRO.
5. Perform the following based on your pump version:

If your pump is...	Then...
SA or MA	Press the radial INPRO oil seal into the bearing frame and make sure that the expulsion part is at the 6 o'clock position and is properly seated.
SX, MX, LA, LX, XLA, XLX, or XXL	Install and tighten the radial-end cover bolt and bearing-frame screws evenly to the torque values shown in the Maximum torque values for 3700 fasteners table.



123	Radial INPRO oil seal
228	Bearing frame

6. Assemble the shaft assembly and bearing frame:
 - a) Coat the outer races of the bearings with a compatible oil.
 - b) Coat the internal bearing surfaces of the bearing frame with a compatible oil.
 - c) Position the oil rings in the grooves of the shaft.



109A	Thrust-bearing end cover
122	Shaft
123A	Thrust deflector
228	Bearing frame
358E	Oil ring inspection plug
360A	Gasket
370N	Bearing-frame screw
390C	Thrust-bearing end-cover shim
469P	Oil ring retainer

- d) Carefully guide the shaft and bearing assembly into the bearing frame until the thrust bearing is seated against the shoulder of the frame. Make sure that the oil rings do not bind or become damaged.
Do not force the assembly together.
 - e) Observe the oil rings through the sight glass in the bearing frame.
If the oil rings are not properly seated in the grooves in the shaft, insert a hook-shaped tool made from wire through the inspection connections. Reposition the oil rings as necessary to seat them in the grooves.
 - f) Check that the shaft turns freely.
If you notice rubbing or binding, determine the cause and correct it.
7. Replace the oil-ring inspection connection plugs.
 8. Replace the two oil-ring retainers.
The screw should bottom against the bearing frame.

Assemble the frame




CAUTION:

- Failure to align the gasket with oil grooves will result in bearing failure from a lack of lubrication.
- Do not over-tighten the thrust-bearing end-cover and bearing-frame screws.
- Do not allow the dial indicator to contact the keyway when turning the shaft. Readings will be incorrect and damage to dial indicator could result.
- For runout checks, firmly support the bearing-frame assembly in the horizontal position.


1. Perform the following based on your pump:

If your pump is...	Then...
SX, MX, LA, LX, XLA, XLX, or XXL	<ol style="list-style-type: none"> 1. Install three thrust-bearing end-cover shims on the thrust-bearing end cover. 2. Align the holes.
SA or MA	<ol style="list-style-type: none"> 1. Install three thrust-bearing end-cover gaskets on the bearing-end cover. 2. Align the gaskets to the end cover so that the openings in the gaskets align with the oil grooves on the end cover.



109A	Thrust-bearing end cover
228	Bearing frame
360A	Thrust-bearing end-cover gaskets

2. Install the thrust-bearing end cover over the shaft and onto the bearing frame.
3. Install and tighten the thrust-bearing end cover and bearing-frame screws evenly to the torque values in the Maximum torque values for 3700 fasteners table.




4. Determine the axial end play as follows:
 - a) Mount the dial indicator.
 - b) Use a lever to apply axial force to the impeller end of the shaft and firmly seat the thrust bearing against the shoulder in the bearing frame.
 - c) Apply axial force in the opposite direction and firmly seat the thrust bearing against the thrust-bearing end cover.
 - d) Repeat steps b and c several times and record the total travel (end play) of the rotating element. Total travel (end play) must fall in the range of 0.001 to 0.005 in. (0.025 to 0.125 mm). Achieve the correct axial end play by adding or removing end-cover gaskets (for SA and MA pumps) or end-cover shims (for SX, MX, LA, LX, XLA, XLX, and XXL pumps) between the thrust-bearing end cover and the bearing frame. Add gaskets and shims if no axial end play is present.
5. Repeat steps 1 through 4.
If the measured total travel falls outside the accepted range in step 4, remove or add the appropriate quantity of individual shims or gaskets to obtain the proper total travel.

6. Perform the following based on your pump:

If your pump is...	Then...
SX, MX, LA, LX, XLA, XLX, or XXL	<ol style="list-style-type: none"> 1. Remove the thrust-bearing end cover. 2. Press the INPRO seal into the thrust-bearing end cover and ensure that the expulsion part is at the 6 o'clock position and is properly seated. 3. Install the O-ring into the groove of the thrust-bearing end cover. 4. Lubricate the O-ring with a suitable lubricant.
SA or MA	<ol style="list-style-type: none"> 1. Remove the thrust-bearing end cover. 2. Press the INPRO seal into the thrust-bearing end cover and ensure that the expulsion part is at the 6 o'clock position and is properly seated.



7. Install the thrust-bearing end cover with O-ring over the shaft and into the bearing-frame bore. Ensure that the O-ring is not damaged while it enters the bearing-frame bore.
8. Perform the following based on whether or not your power end has the optional air-cooling package:



If your power end...	Then...
Has the optional air-cooling package	<ol style="list-style-type: none"> 1. Position the thrust-fan guard support on the thrust-bearing end cover. 2. Install and tighten the thrust-bearing end cover and bearing-frame screws evenly to torque values shown in the Maximum torque values for 3700 fasteners table. 3. Install the thrust fan over the shaft. 4. Position the thrust-deflector fan approximately 0.030 in. (0.8 mm) from the thrust INPRO seal on SA and MA pumps. Place the fan against the coupling-diameter shoulder and tighten the deflector-fan set screw firmly. 5. Tighten the heat-flinger set screws firmly.
Does not have the optional air-cooling package	<ol style="list-style-type: none"> 1. Install and tighten the thrust-bearing end cover and bearing-frame screws evenly to the torque values in the Maximum torque values for 3700 fasteners table. 2. Verify that the shaft turns freely. If you detect rubbing or excessive drag, then determine the cause and correct it.



122	Shaft
123B	Radial deflector fan
123E	Thrust deflector fan
222	Deflector set screw
228	Bearing frame
234	Thrust deflector-fan guard
234D	Thrust deflector-fan guard support
496Q	Support screws

9. Check the following runouts:


Check	Procedure
Shaft impeller fit	<ol style="list-style-type: none"> 1. Mount the dial indicator on the bearing frame. 2. Rotate the shaft through a maximum arc from one side of the keyway to the other. If the total indicator reading is greater than 0.002 in. (0.050 mm), determine the cause and correct it. 
Shaft seal fit	<ol style="list-style-type: none"> 1. Mount the dial indicator. 2. Rotate the shaft so that the indicator rides along the shaft surface for 360°. If the total indicator reading is greater than 0.002 in. (0.050 mm), then determine the cause and correct it. 
Bearing-frame face	<ol style="list-style-type: none"> 1. Mount the dial indicator on the shaft. 2. Rotate the shaft so that the indicator rides along the bearing-frame face for 360°. If the total indicator reading is greater than 0.004 in. (0.10 mm), then disassemble and determine the cause and correct it.

Check	Procedure
	
<p>Bearing-frame lock</p>	<ol style="list-style-type: none"> 1. Mount the dial indicator on the shaft. 2. Rotate the shaft so that the indicator rides along the bearing-frame lock for 360°. If the total indicator reading is greater than 0.004 in. (0.10 mm), then disassemble and determine the cause and correct it. 

10. Install and tighten any plugs and fittings removed during disassembly, including the oil-drain plug, and the sight glass.
11. If your power end has the optional water cooling package, install the finned-tube cooling assembly into the bearing frame.

Install the optional water-jacket cover

1. Install the outer and inner water-jacket-cover O-rings into the grooves in the water jacket cover.




184	Seal-chamber cover
412S	Outer water-jacket-cover O-ring
490	Water jacket cover
497T	Outer and inner water-jacket-cover O-ring

2. Lubricate the sealing surfaces in the seal-chamber cover and O-rings with a suitable lubricant.
3. Insert the water jacket cover with O-rings into the fit in the seal-chamber cover.
Make sure that the water jacket cover enters uniformly and that the O-rings are not damaged.


Install the seal-chamber cover

1. Install the eyebolt in the tapped hole provided in the seal-chamber cover.




122	Shaft
184	Seal-chamber cover
228	Bearing frame
230	Seal-chamber cover wear-ring
370H	Bearing-frame bolts

2. Set up a sling from the eyebolt to the overhead lifting device.
3. Lift the seal-chamber cover and position it so that it aligns with the shaft.
4. Install the seal-chamber cover on the bearing-frame assembly:
 - a) Guide the cover carefully over the shaft and into the bearing-frame lock.
 - b) Install the seal-chamber cover and bearing-frame bolts.
 - c) Tighten the bolts evenly using an alternating pattern.
Torque the bolts to values shown in the Maximum torque values for 3700 fasteners table.
5. Check the seal-chamber cover face runout:
 - a) Mount the dial indicator on the shaft.
 - b) Rotate the shaft so that the indicator rides along the seal-chamber cover face for 360°.
If the total indicator reading is greater than 0.005 in. (0.13 mm), determine the cause and correct it.




6. Check the seal-chamber cover lock runout:
 - a) Mount the dial indicator on the shaft.
 - b) Rotate the shaft so that the indicator rides along the seal-chamber cover lock for 360°. If the total indicator reading is greater than 0.005 in. (0.13 mm), determine the cause and correct it.



NOTICE:

The impeller and wear-ring clearance setting procedures must be followed. Improperly setting the clearance or not following any of the proper procedures can result in sparks, unexpected heat generation, and equipment damage.

7. Check the seal-chamber cover wear-ring runout:
 - a) Mount the dial indicator on the shaft.
 - b) Rotate the shaft so that the indicator rides on the seal-chamber cover wear-ring surface for 360°. If the total indicator reading exceeds 0.006 in. (0.15 mm), determine the cause and correct it.




8. Check the seal-chamber face runout:
 - a) Mount a dial indicator on the shaft.
 - b) Rotate the shaft so that the indicator rides along the seal-chamber face for 360°.

If the total indicator reading is greater than the values shown in this table, determine the cause and correct it.

Table 7: Maximum Allowable Seal Chamber Face Runout


Group	Maximum Allowable Total Indicator Reading
SA	0.0018 in. (0.045 mm)
SX, MA	0.002 in. (0.05 mm)
MX, LA	0.0024 in. (0.06 mm)
LX, XLA	0.0026 in. (0.065 mm)
XLX	0.0028 in. (0.07 mm)
XXL	0.0031 in. (0.08 mm)



9. Check the seal-chamber lock (register) runout:

- a) Mount a dial indicator on the shaft or shaft sleeve.
- b) Rotate the shaft so that the indicator rides along the seal-chamber lock (register) for 360°.

If the total indicator reading is greater than 0.005 in. (0.125 mm), determine the cause and correct it.



Install the cartridge-type mechanical seal and seal-chamber cover


NOTICE:

Refer to the mechanical seal manufacturer's drawings and instructions for assistance during the installation of the mechanical seal.

1. Remove the impeller.
 - a) Loosen and remove the impeller nut.
The impeller nut has left-hand threads.
 - b) Remove the impeller, impeller key, and seal-chamber cover as described in the Disassembly section.
2. Lubricate all O-rings with suitable lubricant, unless the seal manufacturer's instructions indicate otherwise.
3. Slide the cartridge seal assembly (rotary, stationary gland, gland gasket, and sleeve) onto the shaft.

NOTICE:

Ensure that the mechanical-seal gland-piping connections are properly oriented.



122	Shaft
184	Seal-chamber cover
228	Bearing frame
355	Gland stud nut
370H	Bearing-frame bolts

4. Install the seal-chamber cover.
 - a) Set up a sling to the eyebolt and to the overhead lifting device.
 - b) Lift the seal-chamber cover and position it so that it aligns with the shaft.
 - c) Install the seal-chamber cover on the power end by guiding the cover carefully over the cartridge-seal rotary.
Ensure that the gland studs smoothly enter the holes in the cartridge-seal gland and that the cover fits into the bearing frame lock.
 - d) Install the seal-chamber cover and bearing-frame bolts and tighten them using an alternating pattern.
Torque the bolts to the values shown in the Maximum torque values for 3700 fasteners table.
 - e) Install the gland stud nuts and tighten evenly to the torque values shown in the Maximum torque values for 3700 fasteners table.
5. Tighten the setscrews in the locking collar.

6. Disengage the spacer ring or clips.
7. Verify that the shaft turns freely.
If you detect rubbing or excessive drag, then determine the cause and correct it.

Install the impeller



CAUTION:

Wear heavy work gloves when you handle impellers. The sharp edges can cause physical injury.

It is recommended that you repeat the runout checks on the seal-chamber cover face, lock, and wear-ring surfaces as described in *Install the seal-chamber cover* (page 89).

1. Install the impeller key in the keyway of the shaft.
The key should be at the top (12 o'clock) position for the impeller installation.
2. Install the impeller on the shaft.
Apply anti-galling compound to the impeller bore to aid in assembly and disassembly.
3. Install the impeller nut and tighten to the torque values shown in the Maximum torque values for 3700 fasteners table.
The impeller nut has left-hand threads.
4. Tighten the set screw in the end of the impeller nut.
5. Verify that the shaft turns freely.
If you notice any rubbing or excessive drag, then determine the cause and correct it.

It is recommended that you repeat the runout checks on the impeller wear-ring surface as described in *Replace the wear rings*.

Install the coupling hub




CAUTION:

Wear insulated gloves to handle the coupling hub. The coupling hub will get hot and can cause physical injury.

NOTICE:


If it is necessary to heat the coupling hub due to an interference fit, do not use a torch. Use a heating device such as an oven which uniformly heats the coupling hub.

1. Install the key and pump-half coupling hub on the shaft.
2. Make sure that the hub is flush with the end of the shaft or to the mark scribed during disassembly.
Refer to coupling manufacturer's instructions for assistance.



Install the back pull-out assembly in the casing

1. Install a new casing gasket on the gasket surface of the casing.
You can apply anti-galling compound to the casing fits to aid in assembly and disassembly.
2. Replace the back pull-out assembly in the casing using a lifting sling through the bearing frame or other suitable means.



3. Slide the back pull-out assembly into the proper position in the casing by loosening the jacking bolts evenly.
Make sure that the casing gasket is not damaged.
4. Install the casing stud nuts.
5. Inspect the gap between the seal-chamber cover and casing and adjust the casing stud nuts as necessary to make the gap uniform.
6. Tighten the casing stud nuts uniformly, using an alternating pattern, until the seal-chamber cover is in metal-to-metal contact with the casing. Tighten each nut to the torque values shown in the Maximum torque values for 3700 fasteners table.
7. Verify that the shaft turns freely.
If you detect any rubbing or excessive drag, then determine the cause and correct it.
8. Reinstall the coupling spacer, coupling guard, auxiliary piping, tubing, and equipment that was removed during preparation for disassembly.

9. Lubricate the bearings.

Post-assembly checks

Perform these checks after you assemble the pump, then continue with pump startup:

- Rotate the shaft by hand in order to make sure that it rotates easily and smoothly and that there is no rubbing.
- Open the isolation valves and check the pump for leaks.

Assembly references

Maximum torque values for fasteners

About this table

The torque values specified in this table are for dry threads. These values should be reduced for lubricated threads only when lubricants of high stress ability, such as Molycote, are used. Materials listed in this table are equal to the respective API 610, 11th Edition material classes. In some cases, superior materials are substituted.

Construction - API designation

The following API designations apply to this table:

- S-1
- S-3
- S-4
- S-5
- S-6
- S-8
- S-8N
- S-9
- C-6
- A-8
- A-8N
- D-1
- Modified A-8 (non-API material)

Maximum torque values, Nm (ft-lb)

Item number	Item	Group size	Torque
136	Bearing locknut	SA	95 (70)
		MA	122 (90)
		SX, MX, LA	149 (110)
		LX, XLA	190 (140)
		XLX	407 (300)
304	Impeller nut	SA, SX	145 (107)
		MA, MX	178 (131)
		LA, LX, XLA, XLX	287 (212)
353 and 355	Gland studs and nuts	SA	118 (87)
		All other sizes	235 (173)

Item number	Item	Group size	Torque
365A and 425	Casing studs and nuts	SA, SX MA, MX (9 in. and 11 in.)	415 (306)
		MA, MX (13 in.)	671 (495)
		LA, LX (13 in.)	671 (495)
		LA, LX (16 in. and 17 in.)	1006 (742)
		LA, LX (19 in.)	1426 (1052)
		XLX, XLA (21 in.)	1426 (1052)
370H	Screw - bearing frame and seal-chamber cover	SA, MA	41 (30)
		SX	80 (59)
		MX, LA	142 (105)
		LX, XLA	231 (170)
		XLX	346 (256)
370N	Screw - thrust bearing end cover to frame	SA, SX	41 (30)
		MA, MX, LA	41 (30)
		LX, XLA, XLX	80 (59)
370P and 370W (optional)	Screw - radial bearing end cover to frame	SX MX, LA LX, XLA XLX	9 (7)
469Q (optional)	Screw - thrust deflector fan guard support	All	9 (7)
	Pump to base bolts	All	955 (705)

Spare parts

Critical services spare parts

For critical services, the following parts should be stocked, where applicable:

- Impeller (101) with impeller rings (202 and 203)
- Thrust bearing end-cover (109A)
- Radial bearing end cover (119A)
- Shaft (122)
- Radial INPRO seal (123)
- Thrust INPRO (123A)
- Radial heat flinger (123B)
- Thrust fan (123E)
- Impeller key (178)

An alternative approach is to stock a complete back pull-out assembly. This is a group of assembled parts which includes all but the casing and coupling.

Recommended spare parts

When ordering spare parts, always state the serial number, and indicate the part name and item number from the relevant sectional drawing. It is imperative for service reliability to have a sufficient stock of readily available spare parts.

It is suggested that the following spare parts be stocked, where applicable:

- Bearing locknut (136)
- Bearing lockwasher (382)
- Cartridge mechanical seal (383)
- Casing gasket (351)
- Casing wear ring (164)
- Finned-tube cooling assembly (494)
- Impeller nut (304)

- Impeller wear ring - casing side (202)
- Impeller wear ring - cover side (203)
- Oil rings (114)
- Oiler with wire guard (251)
- Radial bearing (168)
- Radial bearing end-cover gasket (360)
- Seal-chamber cover wear ring (230)
- Set screws (222E and 320)
- Throat bushing - seal-chamber cover (125)
- Thrust bearing (duplex pair) (112)
- Thrust bearing end-cover gaskets (360A)
- Thrust bearing end-cover O-ring (412)
- Thrust bearing end-cover shim pack (390C)
- Water jacket cover O-rings (412S and 497T)

Troubleshooting

Operation troubleshooting

Symptom	Cause	Remedy
The pump is not delivering liquid.	The pump is not primed.	Re-prime the pump and check that the pump and suction line are full of liquid.
	The suction line is clogged.	Remove the obstructions.
	The impeller is clogged.	Back-flush the pump in order to clean the impeller.
	The shaft is rotating in the wrong direction.	Change the rotation. The rotation must match the arrow on the bearing housing or pump casing.
	The foot valve or suction pipe opening is not submerged enough.	Consult an ITT representative for the proper submersion depth. Use a baffle in order to eliminate vortices.
	The suction lift is too high.	Shorten the suction pipe.
The pump is not producing the rated flow or head.	The gasket or O-ring has an air leak.	Replace the gasket or O-ring.
	The stuffing box has an air leak.	Replace or readjust the mechanical seal.
	The impeller is partly clogged.	Back-flush the pump in order to clean the impeller.
	The clearance between the impeller and the pump casing is excessive.	Adjust the impeller clearance.
	The suction head is not sufficient.	Make sure that the suction-line shutoff valve is fully open and that the line is unobstructed.
	The impeller is worn or broken.	Inspect and replace the impeller if necessary.
The pump starts and then stops pumping.	The pump is not primed.	Re-prime the pump and check that the pump and suction line are full of liquid.
	The suction line has air or vapor pockets.	Rearrange the piping in order to eliminate air pockets.
	The suction line has an air leak.	Repair the leak.
The bearings are running hot.	The pump and driver are not aligned properly.	Realign the pump and driver.
	There is not sufficient lubrication.	Check the lubricant for suitability and level.
	The lubrication was not cooled properly.	Check the cooling system.
The pump is noisy or vibrates.	The pump and driver are not aligned properly.	Realign the pump and driver.
	The impeller is partly clogged.	Back-flush the pump in order to clean the impeller.
	The impeller or shaft is broken or bent.	Replace the impeller or shaft as necessary.
	The foundation is not rigid.	Tighten the hold-down bolts of the pump and motor. Make sure the baseplate is properly grouted without voids or air pockets.
	The bearings are worn.	Replace the bearings.
	The suction or discharge piping is not anchored or properly supported.	Anchor the suction or discharge piping as necessary according to recommendations in the Hydraulic Institute Standards Manual.
	The pump is cavitating.	Locate and correct the system problem.

Troubleshooting

Symptom	Cause	Remedy
The stuffing box is leaking excessively.	The packing gland is not adjusted properly.	Tighten the gland nuts.
	The stuffing box is not packed properly.	Check the packing and repack the box.
	The mechanical seal parts are worn.	Replace the worn parts.
	The mechanical seal is overheating.	Check the lubrication and cooling lines.
	The shaft sleeve is scored.	Machine or replace the shaft sleeve as necessary.
The motor requires excessive power.	The discharge head has dropped below the rated point and is pumping too much liquid.	Install a throttle valve. If this does not help, then trim the impeller diameter. If this does not help, then contact your ITT representative.
	The liquid is heavier than expected.	Check the specific gravity and viscosity.
	The stuffing-box packing is too tight.	Readjust the packing. If the packing is worn, then replace the packing.
	Rotating parts are rubbing against each other.	Check the parts that are wearing for proper clearances.
	The impeller clearance is too tight.	Adjust the impeller clearance.

Alignment troubleshooting

Symptom	Cause	Remedy
Horizontal (side-to-side) alignment cannot be obtained (angular or parallel).	The driver feet are bolt-bound.	Loosen the pump's hold-down bolts, and slide the pump and driver until you achieve horizontal alignment.
	The baseplate is not leveled properly and is probably twisted.	<ol style="list-style-type: none"> Determine which corners of the baseplate are high or low. Remove or add shims at the appropriate corners. Realign the pump and driver.

Assembly troubleshooting

Table 8: Troubleshooting procedure

Symptom	Cause	Remedy
There is excessive shaft end play.	The internal clearance of the bearings is excessive.	Replace the bearings with a bearing of the correct type.
	The thrust-bearing end cover is loose.	Tighten the screws.
	There are too many shims under the thrust bearing end cover.	Remove the individual shims to obtain the proper thickness.
The runout for the shaft is excessive.	The shaft is bent.	Replace the shaft.
The runout for the bearing-frame flange is excessive.	The shaft is bent.	Replace the shaft.
	The flange of the bearing frame is distorted.	Replace the bearing-frame flange.
The runout for the seal-chamber cover is excessive.	The seal-chamber cover is improperly seated on the frame.	Replace or re-machine the seal-chamber cover.
	There is corrosion or wear on the seal-chamber cover.	Replace the seal-chamber cover.
The runout for the impeller wear ring is excessive.	The shaft is bent.	Replace the shaft.
	The wear ring was machined improperly.	Replace or re-machine the impeller.

Parts Listings and Cross-Sectional Drawings

Parts list

The materials in this table are typical. Refer to the order documentation for the actual materials furnished.

Table 9: Parts list with standard materials of construction

Item	Part name	Quantity per pump	Construction - API designation				
			S-4	S-6	S-8	C-6	A-8
100	Casing	1	1212			1234	1296
101	Impeller	1	1212	1222	1265	1222	1265
109A	Thrust bearing end cover	1	1212				
112	Ball bearing, thrust	1 pair	Steel				
114	Oil ring (SA and MA frames)	1	1618				
114	Oil ring (SX, MX, LA, LX, XLA, XLX, and XXL frames)	2	1618				
119A	Radial bearing end cover	1	Steel				
122	Shaft	1	2238		2256	2244	2256
123	Deflector, radial	1	1618				
123A	Deflector, thrust	1	1618				
123B	Deflector fan, radial	1	1425				
123C	Deflector fan, thrust	1	1425				
125	Throat bushing, seal chamber	1	1001	2244	2256	2244	2256
136	Locknut, bearing	1	Steel				
164	Wear ring, casing	1	1001	1232	1265	1232	1265
168	Ball bearing, radial	1	Steel				
178	Key, impeller	1	2229			2224	2229
184	Seal-chamber cover	1	1212			1234	1296
198A	Set screw, impeller nut	1	2229				
202	Wear ring, impeller	1	1001	1299	1071	1299	1071
203	Wear ring, impeller	1	1001	1299	1071	1299	1071
222	Set screw, deflector	2	2229				
222E	Set screw, stationary wear rings	6	2229				
228	Bearing frame	1	1212				
230	Wear ring, seal-chamber cover	1	1001	1232	1265	1232	1265
234	Deflector fan guard	1	3201				
234D	Support, deflector fan guard	1	3201				
304	Impeller nut	1	2210	2229			
320	Set screw, impeller wear ring	6	2229				
351	Gasket, casing	1	Spiral wound 316 stainless steel				
353	Stud, gland	4	2239				
355	Nut, gland stud	4	2285				

Parts Listings and Cross-Sectional Drawings

Item	Part name	Quantity per pump	Construction - API designation				
			S-4	S-6	S-8	C-6	A-8
356A	Stud, casing	Varies	2239				
360	Gasket, radial bearing end cover	1	Vellumoid				
360A	Gasket, thrust bearing end cover	3	Vellumoid				
370H	Screw, bearing frame and seal-chamber cover	4	2210				
370N	Screw, thrust bearing end cover	5	2210				
370P	Screw, radial bearing end cover	5	2210				
382	Lockwasher, bearing	1	Steel				
390C	Shim pack, thrust bearing end cover	1	304SS				
408A	Plug, oil drain	1	Steel with magnetic insert				
412	O-ring, thrust bearing end cover	1	Buna N				
418	Bolt, jacking	4	2210				
425	Nut, casing stud	Varies	2239				
469P	Retainer, oil ring	2	2285				
494	Finned tube cooling assembly	1	Stainless steel with copper fins				
497F	O-ring, thrust deflector	1	Buna N				
497H	O-ring, radial deflector	1	Buna N				
497S	O-ring, radial end cover	1	Buna N				

Table 10: Materials cross-reference chart

Material	Goulds Pumps Material Code	ASTM Material Designation	Other
Cast iron	1000	A48 Class 25	—
Cast iron	1001	A48 Class 20	—
Nitronic 60	1071	A743 Gr. CF10SMnN	—
Carbon steel	1212	A216 WCB	—
12% chrome steel	1222	A743 Gr. CA6NM	—
12% chrome steel	1232	A743 Gr. CA15	—
12% chrome steel	1234	A487 Gr. CA6MN Class A	—
316L stainless steel	1265	A743 Gr. CF3M	—
316L stainless steel	1296	A351 Gr. CF3M	—
12% chrome steel	1299	A743 Gr. CA15	—
Aluminum	1425	SC64D	UNS A03190
Bismuth bronze	1618	B505 CDA 89320	—
Steel	2210	A108 Gr. 1211	UNS G12110
316 stainless steel	2229	A276 Type 316	—
4140 steel	2238	A434 Gr. 4140 Class BC	—
4140 steel	2239	A193 Gr. B7	—
410 stainless steel	2244	A276 Type 410	UNS S41000
316L stainless steel	2256	A276 Type 316L	UNS S31603

Material	Goulds Pumps Material Code	ASTM Material Designation	Other
4140 steel	2285	A194 Gr. 2H	—
Steel	3201	A283 Grade D	—
316L stainless steel	3223	A240 Type 316L	—

Table 11: Fasteners and plugs

Material	Goulds Pumps Material Code	ASTM
Carbon steel	2210	A307 Grade B
Monel	6162	F468 Alloy 500
316SS	2229	F593 Alloy Group 2
4140 steel	2239	A193 Grade B7
316LSS	2256	A193 Grade B8MLN
4140 steel	2285	A194 Grade 2 H

Local ITT Contacts

Regional offices

Region	Address	Telephone	Fax
North America (Headquarters)	ITT - Goulds Pumps 240 Fall Street Seneca Falls, NY 13148 USA	+1-315-568-2811	+1-315-568-2418
Asia Pacific	ITT Industrial Process 10 Jalan Kilang #06-01 Singapore 159410	+65-627-63693	+65- 627-63685
Europe	ITT - Goulds Pumps Millwey Rise Industrial Estate Axminster, Devon, England EX13 5HU	+44-1297-630250	+44-1297-630256
Latin America	ITT - Goulds Pumps Camino La Colina # 1448 Condominio Industrial El Rosal Huechuraba – Santiago 8580000 Chile	+562-544-7000	+562-544-7001
Middle East and Africa	ITT - Goulds Pumps Achileos Kyrrou 4 Neo Psychiko 115 25 Athens Greece	+30-210-677-0770	+30-210-677-5642



ITT

How did we measure up?

It is our sincere intention to exceed our customer's expectations on every order. Tell us if we achieved our goal on your order. Please take our customer satisfaction survey online at:

www.ittindustrialproducts.com/feedbacksurvey.html

We appreciate you taking the time to provide your feedback. Thank you for buying ITT pumps, parts, and controls.

Contact Us

Goulds Pumps has offices, warehouses and manufacturing facilities worldwide, while doing business in over 100 countries in the Americas, Europe, the Middle East and Asia Pacific. To find your nearest distributor, use our convenient Sales and Service Locator found on our Web site.

Find Sales & Service



*Worldwide Sales and
Service Contracts*

Visit our Web site for the latest version of this document and more information
www.gouldspumps.com